

SPLIT-TYPE AIR CONDITIONERS

## OUTDOOR UNIT

### Revision F:

- 1. TECHNICAL CHANGES for MUZ-HM09/12/15/18NA-**U2** have been corrected.
- Power consumptions for MUZ-HM15/18/24NA, MUZ-HM15/18/24NA2, MUZ-HM15/18/24NAH in 3. SPECIFICATION have been corrected.
- Air flow and fan speed in 3.SPECIFICATION have been corrected.
- 5. WIRING DIAGRAM for MUZ-HM09/12/15/18NA-**U2** have been corrected.
- Some descriptions have been modified.

OBH747 REVISED EDITION-E is void.

# SERVICE MANUAL



No. OBH747  
REVISED EDITION-F

## Models

MUZ-HM09NA - **U1**, **U2**, **U8**

MUZ-HM09NA2 - **U1**, **U8**

MUZ-HM09NAH - **U1**

MUZ-HM12NA - **U1**, **U2**, **U8**

MUZ-HM12NA2 - **U1**, **U8**

MUZ-HM12NAH - **U1**

MUZ-HM15NA - **U1**, **U2**

MUZ-HM15NA2 - **U1**

MUZ-HM15NAH - **U1**

MUZ-HM18NA - **U1**, **U2**

MUZ-HM18NA2 - **U1**


MUZ-HM18NAH - **U1**

MUZ-HM24NA - **U1**

MUZ-HM24NA2 - **U1**

MUZ-HM24NAH - **U1**

Indoor unit service manual  
MSZ-HM•NA Series (OBH746)



MUZ-HM24NA

## CONTENTS

1. TECHNICAL CHANGES .....	3
2. PART NAMES AND FUNCTIONS .....	3
3. SPECIFICATION .....	4
4. OUTLINES AND DIMENSIONS .....	9
5. WIRING DIAGRAM .....	11
6. REFRIGERANT SYSTEM DIAGRAM .....	16
7. DATA .....	20
8. ACTUATOR CONTROL .....	33
9. SERVICE FUNCTIONS .....	34
10. TROUBLESHOOTING .....	35
11. DISASSEMBLY INSTRUCTIONS .....	60

PARTS CATALOG (OBB747)

## Use the specified refrigerant only

### Never use any refrigerant other than that specified.

Doing so may cause a burst, an explosion, or fire when the unit is being used, serviced, or disposed of.

Correct refrigerant is specified in the manuals and on the spec labels provided with our products.

We will not be held responsible for mechanical failure, system malfunction, unit breakdown or accidents caused by failure to follow the instructions.

#### Revision A:

- MUZ-HM09/12NA-[U8], MUZ-HM09/12NA2-[U8], MUZ-HM15/18NA-[U1], MUZ-HM15/18NA2-[U1] and MUZ-HM24NA2-[U1] have been added.

#### Revision B:

- 3. SPECIFICATION has been modified.

#### Revision C:

- MUZ-HM09/12NA-[U1], MUZ-HM09/12NA2-[U1] have been added.

#### Revision D:

- Capacity corrections have been corrected [7-1. 2), 3)].

#### Revision E:

- MUZ-HM09/12/15/18NA-[U2] and MUZ-HM09/12/15/18/24NAH-[U1] have been added.

#### Revision F:

- 1. TECHNICAL CHANGES for MUZ-HM09/12/15/18NA-[U2] have been corrected.
- Power consumptions for MUZ-HM15/18/24NA, MUZ-HM15/18/24NA2, MUZ-HM15/18/24NAH in 3. SPECIFICATION have been corrected.
- Air flow and fan speed in 3.SPECIFICATION have been corrected.
- 5. WIRING DIAGRAM for MUZ-HM09/12/15/18NA-[U2] have been corrected.
- Some descriptions have been modified.

# 1

## TECHNICAL CHANGES

### MUZ-HM24NA - U1

1. New model

### MUZ-HM09NA - U8

### MUZ-HM09NA2 - U8

### MUZ-HM12NA - U8

### MUZ-HM12NA2 - U8

### MUZ-HM15NA - U1

### MUZ-HM15NA2 - U1

### MUZ-HM18NA - U1

### MUZ-HM18NA2 - U1

### MUZ-HM24NA2 - U1

1. New model

### MUZ-HM09NA - U1

### MUZ-HM09NA2 - U1

### MUZ-HM12NA - U1

### MUZ-HM12NA2 - U1

1. New model

### MUZ-HM09NA - U1 → MUZ-HM09NA - U2

### MUZ-HM12NA - U1 → MUZ-HM12NA - U2

1. Fan motor has been changed.
2. Inverter P.C. board has been changed.
3. R.V. coil has been changed.
4. LEV has been changed.
5. Outdoor heat exchanger has been changed.
6. 4-way valve has been changed.
7. Compressor has been changed.

### MUZ-HM15NA - U1 → MUZ-HM15NA - U2

### MUZ-HM18NA - U1 → MUZ-HM18NA - U2

1. Fan motor has been changed.
2. Inverter P.C. board has been changed.
3. LEV has been changed.

### MUZ-HM09NAH - U1

### MUZ-HM12NAH - U1

### MUZ-HM15NAH - U1

### MUZ-HM18NAH - U1


### MUZ-HM24NAH - U1

1. New model


# 2

## PART NAMES AND FUNCTIONS

MUZ-HM09NA MUZ-HM09NA2 MUZ-HM09NAH  
 MUZ-HM12NA MUZ-HM12NA2 MUZ-HM12NAH  
 MUZ-HM15NA MUZ-HM15NA2 MUZ-HM15NAH  
 MUZ-HM18NA MUZ-HM18NA2 MUZ-HM18NAH



MUZ-HM24NA MUZ-HM24NA2 MUZ-HM24NAH



Outdoor unit model			MUZ-HM09NA - <div>U1</div> MUZ-HM09NA2 - <div>U1</div>	MUZ-HM09NA - <div>U2</div> MUZ-HM09NAH - <div>U1</div>	MUZ-HM09NA - <div>U8</div> MUZ-HM09NA2 - <div>U8</div>
Capacity Rated (Minimum~Maximum)	Cooling ※1	Btu/h	9,000 ( 3,800 ~ 10,000 )		
	Heating 47 ※1	Btu/h	10,900 ( 4,500 ~ 11,800 )		
Capacity Rated (Maximum)	Heating 17 ※2	Btu/h	6,700 (7,200)		
Power consumption Rated (Minimum~Maximum)	Cooling ※1	W	750 (240 - 850)		750 (205 - 850)
	Heating 47 ※1	W	900 (240 - 1,000)		900 (255 - 1,000)
Power consumption Rated (Maximum)	Heating 17 ※2	W	700 (780)		
EER ※1 [SEER] ※3	Cooling		12.0 [ 18.0 ]		
HSPF IV ※4	Heating		10.0 (NA)/8.5 (NA2)/9.0 (NAH)		
COP	Heating ※1		3.55		
Power factor	Cooling (208/230)	%	87/87		84/84
	Heating (208/230)	%	90/90		90/89
Power supply	V , phase , Hz		208/230 , 1 , 60		
Max. fuse size (time delay)		A	15		
Min. circuit ampacity		A	9		12
Fan motor	F.L.A	A	0.50		
Compressor	Model		KNB073FRVMC	KNB073FRXMC	KNB073FQDHC
	R.L.A	A	6.2		6.6
	L.R.A	A	7.7		8.2
	Refrigeration oil	fl oz. (L) (Model)	9.1 (0.27) (FV50S)		10.8 (0.32) (NEO22)
Refrigerant control			Linear expansion valve		
Sound level ※1	Cooling	dB(A)	46		
	Heating	dB(A)	50		
Airflow High - Med. - Low	Cooling	CFM	1,063 - 1,063 - 1,063		
	Heating	CFM	1,282 - 1,105 - 1,105		1,240 - 1,105 - 1,105
Fan speed High - Med. - Low	Cooling	rpm	740 -740 -740		
	Heating	rpm	890 - 770- 770		860 - 770 - 770
Defrost method			Reverse cycle		
Dimensions	W	in.	31-1/2		
	D	in.	11-1/4		
	H	in.	21-5/8		
Weight		lb.	73		
External finish			Munsell 3Y 7.8/1.1		
Refrigerant piping			Not supplied		
Refrigerant pipe size (Min. wall thickness)	Liquid	in.	1/4 (0.0315)		
	Gas	in.	3/8 (0.0315)		
Connection method	Indoor		Flared		
	Outdoor		Flared		
Between the indoor & outdoor units	Height difference	ft.	40		
	Piping length	ft.	65		
Refrigerant charge (R410A)			1 lb. 12 oz.		

**NOTE:** Test conditions are based on AHRI 210/240.

\*1: Rating conditions (Cooling) — Indoor: 80°FDB, 67°F WB, Outdoor: 95°FDB, (75°F WB)  
(Heating) — Indoor: 70°FDB, 60°F WB, Outdoor: 47°FDB, 43°F WB

\*2: (Heating) — Indoor: 70°FDB, 60°F WB, Outdoor: 17°FDB, 15°F WB

\*3: Test condition (Refer to 3-1.)

\*4: Test condition (Refer to 3-1.)





Outdoor unit model			MUZ-HM12NA - [U1] MUZ-HM12NA2 - [U1]	MUZ-HM12NA - [U2] MUZ-HM12NAH - [U1]	MUZ-HM12NA - [U8] MUZ-HM12NA2 - [U8]
Capacity	Cooling *1	Btu/h	12,000 ( 3,800 ~ 12,200 )		
Rated (Minimum~Maximum)	Heating 47 *1	Btu/h	12,200 ( 4,500 ~ 14,500 )		12,200 ( 5,500 ~ 14,500 )
Capacity	Heating 17 *2	Btu/h	7,600 (9,000)		
Rated (Maximum)					
Power consumption	Cooling *1	W	1,210 (240 - 1,300)		1,210 (205 - 1,300)
Rated (Minimum~Maximum)	Heating 47 *1	W	990 (240 - 1,220)		990 (340 - 1,660)
Power consumption	Heating 17 *2	W	800 (990)		
Rated (Maximum)					
EER *1 [SEER] *3	Cooling		9.9 [ 18.0 ]		
HSPF IV *4	Heating		10.0 (NA)/8.5 (NA2)/9.0 (NAH)		
COP	Heating *1		3.61		
Power factor	Cooling (208/230)	%	95/95		94/94
	Heating (208/230)	%	93/93		95/96
Power supply	V , phase , Hz		208/230 , 1 , 60		
Max. fuse size (time delay)	A		15		
Min. circuit ampacity	A		9		12
Fan motor	F.L.A	A	0.50		
Compressor	Model		KNB073FRVMC	KNB073FRXMC	KNB092FQAHC
	R.L.A	A	6.2		6.6
	L.R.A	A	7.7		8.2
	Refrigeration oil	fl oz. (L) (Model)	9.1 (0.27) (FV50S)		10.8 (0.32) (NEO22)
Refrigerant control			Linear expansion valve		
Sound level *1	Cooling	dB(A)	49		
	Heating	dB(A)	51		
Airflow	Cooling	CFM	1,063 - 1,063 - 1,063		1,102 - 1,102 - 639
High - Med. - Low	Heating	CFM	1,282 - 1,105 - 1,105		1,186 - 1,116 - 1,045
Fan speed	Cooling	rpm	740- 740 -740		810 - 810 - 490
High - Med. - Low	Heating	rpm	890 - 770 - 770		870 - 820 - 770
Defrost method			Reverse cycle		
Dimensions	W	in.	31-1/2		
	D	in.	11-1/4		
	H	in.	21-5/8		
Weight	lb.		73		
External finish			Munsell 3Y 7.8/1.1		
Refrigerant piping			Not supplied		
Refrigerant pipe size	Liquid	in.	1/4 (0.0315)		
(Min. wall thickness)	Gas	in.	3/8 (0.0315)		
Connection method	Indoor		Flared		
	Outdoor		Flared		
Between the indoor & outdoor units	Height difference	ft.	40		
	Piping length	ft.	65		
Refrigerant charge (R410A)			1 lb. 12 oz.		2 lb. 9 oz.

**NOTE:** Test conditions are based on AHRI 210/240.

\*1: Rating conditions (Cooling) — Indoor: 80°FDB, 67°FWB, Outdoor: 95°FDB, (75°FWB)

(Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 47°FDB, 43°FWB

\*2: (Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 17°FDB, 15°FWB

\*3: Test condition (Refer to 3-1.)

\*4: Test condition (Refer to 3-1.)

--	--	--	--	--

Outdoor unit model			MUZ-HM15NA MUZ-HM15NA2 MUZ-HM15NAH	MUZ-HM18NA MUZ-HM18NA2 MUZ-HM18NAH
Capacity Rated (Minimum~Maximum)	Cooling *1	Btu/h	14,000 (3,100 - 16,000)	17,200 (5,800 - 18,000)
	Heating 47 *1	Btu/h	18,000 (4,800 - 18,500)	18,000 (5,400 - 20,900)
Capacity Rated (Maximum)	Heating 17 *2	Btu/h	11,500 (14,000)	11,500 (15,000)
Power consumption Rated (Minimum~Maximum)	Cooling *1	W	1,170 (230 - 2,000)	1,640 (350 - 2,070)
	Heating 47 *1	W	1,600 (220 - 2,010)	1,590 (330 - 2,250)
Power consumption Rated (Maximum)	Heating 17 *2	W	1,300 (1,850)	1,300 (1,950)
EER *1 [SEER] *3	Cooling		12.0 [18.0]	10.5 [18.0]
HSPF IV *4	Heating		10.0 [NA] / 8.5 [NA2] / 9.0 [NAH]	
COP	Heating *1		3.30	3.32
Power factor	Cooling (208/230)	%	98/98	98/98
	Heating (208/230)	%	98/98	97/97
Power supply	V , phase , Hz		208/230, 1 , 60	208/230, 1 , 60
Max. fuse size (time delay)	A		15	15
Min. circuit ampacity	A		10	10
Fan motor	F.L.A	A	0.50	0.50
Compressor	Model		SNB130FQBMT	SNB130FQBMT
	R.L.A	A	7.4	7.4
	L.R.A	A	9.3	9.3
	Refrigeration oil	fl oz. (L) (Model)	11.8 (0.35) (FV50S)	11.8 (0.35) (FV50S)
Refrigerant control	Linear expansion valve			
Sound level *1	Cooling	dB(A)	49	49
	Heating	dB(A)	51	51
Airflow High - Med. - Low	Cooling	CFM	1,102 - 1,102 - 639	1,102 - 1,102 - 639
	Heating	CFM	1,186 - 1,045 - 1,045	1,186 - 1,045 - 1,045
Fan speed High - Med. - Low	Cooling	rpm	810 - 810 - 490	810 - 810 - 490
	Heating	rpm	870 - 770 - 770	870 - 770 - 770
Defrost method	Reverse cycle			
Dimensions	W	in.	31-1/2	31-1/2
	D	in.	11-1/4	11-1/4
	H	in.	21-5/8	21-5/8
Weight		lb.	81	81
External finish	Munsell 3Y 7.8/1.1			
Refrigerant piping	Not supplied			
Refrigerant pipe size (Min. wall thickness)	Liquid	in.	1/4 (0.0315)	1/4 (0.0315)
	Gas	in.	1/2 (0.0315)	1/2 (0.0315)
Connection method	Indoor		Flared	Flared
	Outdoor		Flared	Flared
Between the indoor & outdoor units	Height difference	ft.	40	40
	Piping length	ft.	65	65
Refrigerant charge (R410A)			2 lb. 9 oz.	2 lb. 10 oz.

**NOTE:** Test conditions are based on AHRI 210/240.

\*1: Rating conditions (Cooling) — Indoor: 80°FDB, 67°F WB, Outdoor: 95°FDB, (75°F WB)  
(Heating) — Indoor: 70°FDB, 60°F WB, Outdoor: 47°FDB, 43°F WB

\*2: (Heating) — Indoor: 70°FDB, 60°F WB, Outdoor: 17°FDB, 15°F WB

\*3: Test condition (Refer to 3-1.)

\*4: Test condition (Refer to 3-1.)



Outdoor unit model			<b>MUZ-HM24NA</b> <b>MUZ-HM24NA2</b> <b>MUZ-HM24NAH</b>
Capacity Rated (Minimum~Maximum)	Cooling ※1	Btu/h	22,500 (5,800 ~ 22,500)
	Heating 47 ※1	Btu/h	26,000 (5,400 ~ 26,000)
Capacity Rated (Maximum)	Heating 17 ※2	Btu/h	18,500 (18,500)
Power consumption Rated (Minimum~Maximum)	Cooling ※1	W	2,630 (330 - 2,630)
	Heating 47 ※1	W	2,500 (320 - 2,500)
Power consumption Rated (Maximum)	Heating 17 ※2	W	2,300 (2,300)
EER ※1 [SEER] ※3	Cooling		8.6 [18.0]
HSPF IV ※4	Heating		9.5 [NA] / 8.5 [NA2] / 9.0 [NAH]
COP	Heating ※1		3.05
Power factor	Cooling (208/230)	%	99/99
	Heating (208/230)	%	99/99
Power supply	V , phase , Hz		208/230, 1 , 60
Max. fuse size (time delay)		A	15
Min. circuit ampacity		A	14
Fan motor		F.L.A	0.93
Compressor	Model		SNB130FQBMT
		R.L.A	10
		L.R.A	12.5
	Refrigeration oil	fl oz. (L) (Model)	11.8 (0.35) (FV50S)
Refrigerant control			Linear expansion valve
Sound level ※1	Cooling	dB(A)	54
	Heating	dB(A)	55
Airflow High - Med. - Low	COOL	CFM	1,742 - 1,742 - 922
	HEAT	CFM	1,691 - 1,691 - 1,372
Fan speed High - Med. - Low	Cooling	rpm	840 - 840 - 450
	Heating	rpm	810 - 810 - 650
Defrost method			Reverse cycle
Dimensions	W	in.	33-1/16
	D	in.	13
	H	in.	34-5/8
Weight		lb.	121
External finish			Munsell 3Y 7.8/1.1
Refrigerant piping			Not supplied
Refrigerant pipe size (Min. wall thickness)	Liquid	in.	3/8 (0.0315)
	Gas	in.	5/8 (0.0315)
Connection method	Indoor		Flared
	Outdoor		Flared
Between the indoor & outdoor units	Height difference	ft.	50
	Piping length	ft.	100
Refrigerant charge (R410A)			3 lb. 9 oz.

**NOTE:** Test conditions are based on AHRI 210/240.

※1: Rating conditions (Cooling) — Indoor: 80°FDB, 67°FWB, Outdoor: 95°FDB, (75°FWB)  
(Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 47°FDB, 43°FWB

※2: (Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 17°FDB, 15°FWB

### 3-1. TEST CONDITION

\*3,\*4

ARI	Mode	Test	Indoor air condition (°F)		Outdoor air condition (°F)	
			Dry bulb	Wet bulb	Dry bulb	Wet bulb
	SEER (Cooling)	"A-2" Cooling steady state at rated compressor speed	80	67	95	(75)
		"B-2" Cooling steady state at rated compressor speed	80	67	82	(65)
		"B-1" Cooling steady state at minimum compressor speed	80	67	82	(65)
		"F-1" Cooling steady state at minimum compressor speed	80	67	67	(53.5)
		"E-V" Cooling steady state at intermediate compressor speed *5	80	67	87	(69)
	HSPF (Heating)	"H1-2" Heating steady state at rated compressor speed	70	60	47	43
		"H3-2" Heating at rated compressor speed	70	60	17	15
		"H0-1" Heating steady state at minimum compressor speed	70	60	62	56.5
		"H1-1" Heating steady state at minimum compressor speed	70	60	47	43
		"H2-V" Heating at intermediate compressor speed *5	70	60	35	33

\*5: at intermediate compressor speed

= ("Rated compressor speed" - "minimum compressor speed") / 3 + "minimum compressor speed".

### 3-2. OPERATING RANGE

#### (1) POWER SUPPLY

	Rated voltage	Guaranteed voltage (V)
Outdoor unit	208/230 V 1 phase 60 Hz	<div> Min. 187 208 230 Max. 253 </div>


#### (2) OPERATION

Mode	Condition	Intake air temperature (°F)			
		Indoor		Outdoor	
		DB	WB	DB	WB
Cooling	Standard temperature	80	67	95	—
	Maximum temperature	90	73	115	—
	Minimum temperature	67	57	14	—
	Maximum humidity	78 %		—	
Heating	Standard temperature	70	60	47	43
	Maximum temperature	80	67	75	65
	Minimum temperature	70	60	-4 (NA/NAH), 5(NA2)	-5 (NA/NAH), 4 (NA2)

## OUTLINES AND DIMENSIONS

MUZ-HM09NA MUZ-HM09NA2 MUZ-HM09NAH MUZ-HM12NA MUZ-HM12NA2 MUZ-HM12NAH  
MUZ-HM15NA MUZ-HM15NA2 MUZ-HM15NAH MUZ-HM18NA MUZ-HM18NA2 MUZ-HM18NAH

\*1 4 in. (100 mm) or more when front and sides of the unit are clear








# MUZ-HM24NA MUZ-HM24NA2 MUZ-HM24NAH

Unit: inch


## REQUIRED SPACE

\*1 20 in. (500 mm) or more when front and sides of the unit are clear




**MUZ-HM09NA - [U1] MUZ-HM09NA2 - [U1] MUZ-HM12NA - [U1] MUZ-HM12NA2 - [U1]**


SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
C61,C62	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61	DIODE MODULE	MC	COMPRESSOR	TB	TERMINAL BLOCK
F701,F801,F901	FUSE (T3, 15AL250V)	MF	FAN MOTOR	T801	TRANSFORMER
H	DEFROST HEATER(OPTION PARTS)	PTC64, PTC65	CIRCUIT PROTECTION	X63, X64, X66	RELAY
IC700,IC932	POWER MODULE	RT61	DEFROST THERMISTOR	21S4	REVERSING VALVE COIL
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	26H	HEATER PROTECTOR(OPTION PARTS)
LED	LED	RT64	FIN TEMP. THERMISTOR		
LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR		

**MUZ-HM09NA - [U2] MUZ-HM12NA - [U2]**



SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR
C61,C62	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61,DB65	DIODE MODULE	MC	COMPRESSOR	TB	TERMINAL BLOCK
F701,F801,F901	FUSE (T3, 15AL250V)	MF	FAN MOTOR	T801	TRANSFORMER
H	DEFROST HEATER(OPTION PARTS)	Q821	SWITCHING POWER TRANSISTOR	X63, X64, X66	RELAY
IC700,IC932	POWER MODULE	RT61	DEFROST THERMISTOR	21S4	REVERSING VALVE COIL
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	26H	HEATER PROTECTOR(OPTION PARTS)
LED	LED	RT64	FIN TEMP. THERMISTOR		

# MUZ-HM09NA - U8 MUZ-HM09NA2 - U8 MUZ-HM12NA - U8 MUZ-HM12NA2 - U8



SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
C62, C63	SMOOTHING CAPACITOR	LEV	EXPANSION VALVE COIL	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR.
DB61, DB65	DIODE MODULE	MC	COMPRESSOR	TB1, TB2	TERMINAL BLOCK
F701, F801, F901	FUSE (T3, 15AL250V)	MF	FAN MOTOR	TR821	SWITCHING POWER TRANSISTOR
H	DEFROST HEATER(OPTION PARTS)	PTC64, PTC65	CIRCUIT PROTECTION	T801	TRANSFORMER
IC802	POWER DEVICE	RT61	DEFROST THERMISTOR	X63, X64, X66	RELAY
IPM, IC932	POWER MODULE	RT62	DISCHARGE TEMP. THERMISTOR	21S4	REVERSING VALVE COIL
L61	REACTOR	RT64	FIN TEMP. THERMISTOR	26H	HEATER PROTECTOR(OPTION PARTS)
LED	LED	RT65	AMBIENT TEMP. THERMISTOR		


## MUZ-HM09NAH MUZ-HM12NAH



SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR
C61, C62	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61, DB65	DIODE MODULE	MC	COMPRESSOR	TB	TERMINAL BLOCK
F701, F801, F901	FUSE (T3, 15AL250V)	MF	FAN MOTOR	T801	TRANSFORMER
H	DEFROST HEATER	Q821	SWITCHING POWER TRANSISTOR	X63, X64, X66	RELAY
IC700, IC932	POWER MODULE	RT61	DEFROST THERMISTOR	21S4	REVERSING VALVE COIL
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	26H	HEATER PROTECTOR
LED	LED	RT64	FIN TEMP. THERMISTOR		



**MUZ-HM15NA - [U1] MUZ-HM15NA2 - [U1] MUZ-HM18NA - [U1] MUZ-HM18NA2 - [U1]**




**REMARQUES :**

- Pour le câblage électronique côté intérieur, se reporter au schéma d'entretien du câblage électronique de l'appareil intérieur.
- Utiliser des fils d'alimentation en cuivre.
- Les symboles ont les :Borne significations suivantes, :Connecteur

SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
C61,C62,C63	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61	DIODE MODULE	MC	COMPRESSOR	TB	TERMINAL BLOCK
F701,F801,F901	FUSE (T3, 15A/250V)	MF	FAN MOTOR	T801	TRANSFORMER
H	DEFROST HEATER(OPTION PARTS)	PTC64, PTC65	CIRCUIT PROTECTION	X63, X64, X66	RELAY
IC700,IC820,IC932	POWER MODULE	RT61	DEFROST THERMISTOR	21S4	REVERSING VALVE COIL
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	26H	HEATER PROTECTOR(OPTION PARTS)
LED	LED	RT64	FIN TEMP. THERMISTOR		
LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR		

**MUZ-HM15NA - [U2] MUZ-HM18NA - [U2]**




**REMARQUES :**

- Pour le câblage électronique côté intérieur, se reporter au schéma d'entretien du câblage électronique de l'appareil intérieur.
- Utiliser des fils d'alimentation en cuivre.
- Les symboles ont les :Borne significations suivantes, :Connecteur

SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR
C61,C62,C63	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61,DB65	DIODE MODULE	MC	COMPRESSOR	TB	TERMINAL BLOCK
F701,F801,F901	FUSE (T3, 15A/250V)	MF	FAN MOTOR	T801	TRANSFORMER
H	DEFROST HEATER(OPTION PARTS)	Q821	SWITCHING POWER TRANSISTOR	X63, X64, X66	RELAY
IC700,IC932	POWER MODULE	RT61	DEFROST THERMISTOR	21S4	REVERSING VALVE COIL
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	26H	HEATER PROTECTOR(OPTION PARTS)
LED	LED	RT64	FIN TEMP. THERMISTOR		

## MUZ-HM15NAH MUZ-HM18NAH



### NOTES :


1. About the indoor side electric wiring, refer to the indoor unit electric wiring diagram for servicing.
2. Use copper supply wires.
3. Symbols indicate, :Terminal block :Connector

### REMARQUES :

1. Pour le câblage électronique côté intérieur, se reporter au schéma d'entretien du câblage électronique de l'appareil intérieur.
2. Utiliser des fils d'alimentation en cuivre.
3. Les symboles ont les significations suivantes, :Borne :Connecteur


SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR
C61,C62,C63	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61,DB65	DIODE MODULE	MC	COMPRESSOR	TB	TERMINAL BLOCK
F701,F801,F901	FUSE (T3, 15AL250V)	MF	FAN MOTOR	T801	TRANSFORMER
H	DEFROST HEATER	Q821	SWITCHING POWER TRANSISTOR	X63, X64, X66	RELAY
IC700,IC932	POWER MODULE	RT61	DEFROST THERMISTOR	21S4	REVERSING VALVE COIL
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	26H	HEATER PROTECTOR
LED	LED	RT64	FIN TEMP. THERMISTOR		

## MUZ-HM24NA MUZ-HM24NA2



SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
C61, C62, C63	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR.
DB61	DIODE MODULE	MC	COMPRESSOR	TB	TERMINAL BLOCK
F701, F801, F901	FUSE (T3.15A/250V)	MF	FAN MOTOR	T801	TRANSFORMER
H	DEFROST HEATER (OPTION PARTS)	PTC64, PTC65	CIRCUIT PROTECTION	X63, X64, X66	RELAY
IC700, IC820, IC932	POWER MODULE	RT61	DEFROST THERMISTOR	21S4	REVERSING VALVE COIL
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	26H	HEATER PROTECTOR (OPTION PARTS)
LED	LED	RT64	FIN TEMP. THERMISTOR		
LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR		

## MUZ-HM24NAH




SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT65	AMBIENT TEMP. THERMISTOR
C61, C62, C63	SMOOTHING CAPACITOR	L61	REACTOR	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB61	DIODE MODULE	MC	COMPRESSOR	TB	TERMINAL BLOCK
F701, F801, F901	FUSE (T3.15A/250V)	MF	FAN MOTOR	T801	TRANSFORMER
H	DEFROST HEATER	PTC64, PTC65	CIRCUIT PROTECTION	X63, X64, X66	RELAY
IC700, IC820, IC932	POWER MODULE	RT61	DEFROST THERMISTOR	21S4	REVERSING VALVE COIL
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	26H	HEATER PROTECTOR
LED	LED	RT64	FIN TEMP. THERMISTOR		


MUZ-HM09NA - U1, U2 MUZ-HM09NA2 - U1 MUZ-HM09NAH

MUZ-HM12NA - U1, U2 MUZ-HM12NA2 - U1 MUZ-HM12NAH

Unit: Inch (mm)




MUZ-HM09NA - U8 MUZ-HM09NA2 - U8




**MUZ-HM12NA - U8 MUZ-HM12NA2 - U8**

Unit: Inch (mm)




**MUZ-HM15NA MUZ-HM15NA2 MUZ-HM15NAH  
MUZ-HM18NA MUZ-HM18NA2 MUZ-HM18NAH**

Refrigerant pipe  $\phi 1/2$  ( $\phi 12.7$ )  
(with heat insulator)




# MUZ-HM24NA MUZ-HM24NA2 MUZ-HM24NAH

Unit: Inch (mm)



## MAX. REFRIGERANT PIPING LENGTH and MAX. HEIGHT DIFFERENCE

Model	Refrigerant piping: ft.		Piping size O.D: in.	
	Max. Length A	Max. Height difference B	Gas	Liquid
MUZ-HM09NA(H) MUZ-HM09NA2 MUZ-HM12NA(H) MUZ-HM12NA2	65	40	3/8	1/4
MUZ-HM15NA(H) MUZ-HM15NA2 MUZ-HM18NA(H) MUZ-HM18NA2			1/2	
MUZ-HM24NA(H) MUZ-HM24NA2	100	50	5/8	3/8



## ADDITIONAL REFRIGERANT CHARGE (R410A: oz.)

**NOTE:** Refrigerant piping exceeding 25 ft. requires additional refrigerant charge according to the calculation.

Model	Outdoor unit precharged	Refrigerant piping length (one way): ft.					
		25	30	40	50	60	65
MUZ-HM09NA(H) MUZ-HM09NA2 MUZ-HM12NA - <span>U1</span> , <span>U2</span> MUZ-HM12NAH - <span>U1</span> MUZ-HM12NA2 - <span>U1</span>	1 lb. 12 oz.	0	1.08	3.24	5.40	7.56	8.64
MUZ-HM12NA - <span>U8</span> MUZ-HM12NA2 - <span>U8</span> MUZ-HM15NA(H) MUZ-HM15NA2	2 lb. 9 oz.						
MUZ-HM18NA(H) MUZ-HM18NA2	2 lb. 10 oz.						

Calculation: X oz. = 1.08/5 oz./ft. × (Refrigerant piping length (ft.) - 25)

Model	Outdoor unit precharged	Refrigerant piping length (one way): ft.								
		25	30	40	50	60	70	80	90	100
MUZ-HM24NA(H) MUZ-HM24NA2	3 lb. 9 oz.	0	1.08	3.24	5.40	7.56	9.72	11.88	14.04	16.20

Calculation: X oz. = 1.08/5 oz./ft. × (Refrigerant piping length (ft.) - 25)

**MUZ-HM09NA MUZ-HM09NA2 MUZ-HM09NAH MUZ-HM12NA MUZ-HM12NA2 MUZ-HM12NAH**  
**MUZ-HM15NA MUZ-HM15NA2 MUZ-HM15NAH MUZ-HM18NA MUZ-HM18NA2 MUZ-HM18NAH**  
**MUZ-HM24NA MUZ-HM24NA2 MUZ-HM24NAH**

## 7-1. PERFORMANCE DATA

### 1) COOLING CAPACITY

Model	Indoor air IWB (°F)	Outdoor intake air DB temperature (°F)														
		75			85			95			105			115		
		TC	SHC	TPC	TC	SHC	TPC	TC	SHC	TPC	TC	SHC	TPC	TC	SHC	TPC
<b>MUZ-HM09NA(H)</b> <b>MUZ-HM09NA2</b>	71	11.0	7.6	0.67	10.3	7.1	0.73	9.7	6.6	0.79	9.0	6.2	0.83	8.3	5.7	0.86
	67	10.4	8.6	0.63	9.7	8.0	0.69	9.0	7.4	0.75	8.4	6.9	0.80	7.7	6.3	0.83
	63	9.8	9.4	0.60	9.1	8.7	0.66	8.5	8.1	0.72	7.7	7.3	0.77	7.0	6.7	0.80
<b>MUZ-HM12NA(H)</b> <b>MUZ-HM12NA2</b>	71	14.7	9.4	1.08	13.7	8.7	1.18	12.9	8.2	1.27	12.0	7.6	1.34	11.0	7.0	1.39
	67	13.9	10.7	1.02	13.0	10.0	1.12	12.0	9.2	1.21	11.2	8.6	1.28	10.3	7.9	1.34
	63	13.1	11.8	0.97	12.1	10.9	1.07	11.3	10.2	1.16	10.3	9.3	1.23	9.4	8.5	1.28
<b>MUZ-HM15NA(H)</b> <b>MUZ-HM15NA2</b>	71	17.2	11.1	1.04	16.0	10.4	1.14	15.1	9.7	1.23	14.0	9.1	1.29	12.9	8.3	1.35
	67	16.2	12.7	0.98	15.1	11.8	1.08	14.0	10.9	1.17	13.0	10.2	1.24	12.0	9.3	1.30
	63	15.3	13.9	0.94	14.1	12.9	1.04	13.2	12.0	1.12	12.0	10.9	1.19	10.9	10.0	1.24
<b>MUZ-HM18NA(H)</b> <b>MUZ-HM18NA2</b>	71	21.1	15.3	1.46	19.7	14.3	1.60	18.5	13.4	1.72	17.2	12.5	1.81	15.8	11.5	1.89
	67	20.0	17.2	1.38	18.6	16.0	1.52	17.2	14.8	1.64	16.0	13.8	1.74	14.7	12.6	1.82
	63	18.7	18.6	1.31	17.4	17.3	1.45	16.2	16.1	1.57	14.7	14.6	1.67	13.4	13.3	1.74
<b>MUZ-HM24NA(H)</b> <b>MUZ-HM24NA2</b>	71	27.6	20.9	2.34	25.8	19.5	2.56	24.2	18.3	2.76	22.5	17.0	2.91	20.7	15.7	3.02
	67	26.1	23.2	2.21	24.3	21.6	2.43	22.5	20.0	2.63	20.9	18.6	2.79	19.2	17.1	2.92
	63	24.5	25.1	2.10	22.7	23.3	2.33	21.2	21.6	2.51	19.2	19.7	2.68	17.6	18.0	2.79

**NOTE:** 1. IWB : Intake air wet-bulb temperature TC : Total Capacity (x10<sup>3</sup> Btu/h)  
 SHC : Sensible Heat Capacity (x10<sup>3</sup> Btu/h) TPC : Total Power Consumption (kW)  
 2. SHC is based on 80°F of indoor Intake air DB temperature.

### 2) COOLING CAPACITY CORRECTIONS

Model	Refrigerant piping length (one way: ft.)			
	25 (std.)	40	65	100
<b>MUZ-HM09NA(H)</b> <b>MUZ-HM09NA2</b> <b>MUZ-HM12NA(H)</b> <b>MUZ-HM12NA2</b> <b>MUZ-HM15NA(H)</b> <b>MUZ-HM15NA2</b>	1.0	0.988	0.967	—
<b>MUZ-HM18NA(H)</b> <b>MUZ-HM18NA2</b>	1.0	0.985	0.963	—
<b>MUZ-HM24NA(H)</b> <b>MUZ-HM24NA2</b>	1.0	0.983	0.956	0.921



### 3) HEATING CAPACITY CORRECTIONS

Model	Refrigerant piping length (one way: ft.)			
	25 (std.)	40	65	100
MUZ-HM09NA(H) MUZ-HM09NA2 MUZ-HM12NA(H) MUZ-HM12NA2 MUZ-HM15NA(H) MUZ-HM15NA2 MUZ-HM18NA(H) MUZ-HM18NA2	1.0	0.997	0.993	—
MUZ-HM24NA(H) MUZ-HM24NA2	1.0	0.997	0.993	0.987

### 4) HEATING CAPACITY

Model	Indoor air IDB (°F)	Outdoor intake air WB temperature (°F)													
		5		15		25		35		43		45		55	
		TC	TPC	TC	TPC	TC	TPC	TC	TPC	TC	TPC	TC	TPC	TC	TPC
MUZ-HM09NA(H) MUZ-HM09NA2	75	4.8	0.53	6.3	0.67	7.9	0.79	9.4	0.88	10.6	0.92	11.0	0.94	12.4	0.97
	70	5.2	0.51	6.7	0.65	8.2	0.77	9.6	0.86	10.9	0.90	11.2	0.92	12.7	0.95
	65	5.5	0.49	6.9	0.62	8.6	0.74	10.0	0.83	11.2	0.88	11.6	0.89	13.0	0.94
MUZ-HM12NA(H) MUZ-HM12NA2	75	5.4	0.58	7.1	0.74	8.8	0.87	10.6	0.97	11.9	1.01	12.3	1.03	13.9	1.07
	70	5.8	0.56	7.5	0.71	9.2	0.85	10.8	0.94	12.2	0.99	12.6	1.01	14.2	1.05
	65	6.1	0.53	7.7	0.68	9.6	0.82	11.2	0.92	12.6	0.97	12.9	0.98	14.5	1.03
MUZ-HM15NA(H) MUZ-HM15NA2	75	7.9	0.94	10.4	1.19	13.1	1.40	15.6	1.56	17.6	1.64	18.1	1.66	20.5	1.73
	70	8.6	0.90	11.1	1.15	13.5	1.37	15.9	1.52	18.0	1.60	18.5	1.63	21.0	1.70
	65	9.0	0.86	11.3	1.10	14.1	1.32	16.5	1.48	18.5	1.56	19.1	1.58	21.4	1.66
MUZ-HM18NA(H) MUZ-HM18NA2	75	7.9	0.94	10.4	1.18	13.1	1.39	15.6	1.55	17.6	1.63	18.1	1.65	20.5	1.72
	70	8.6	0.90	11.1	1.14	13.5	1.36	15.9	1.51	18.0	1.59	18.5	1.62	21.0	1.69
	65	9.0	0.86	11.3	1.10	14.1	1.31	16.5	1.47	18.5	1.55	19.1	1.57	21.4	1.65
MUZ-HM24NA(H) MUZ-HM24NA2	75	11.4	1.48	15.1	1.86	18.9	2.19	22.5	2.44	25.4	2.56	26.1	2.60	29.6	2.70
	70	12.4	1.41	16.0	1.80	19.5	2.14	23.0	2.38	26.0	2.50	26.8	2.55	30.3	2.65
	65	13.0	1.35	16.4	1.73	20.4	2.06	23.8	2.31	26.8	2.44	27.6	2.48	30.9	2.60

**NOTE:** 1. IDB : Intake air dry-bulb temperature

TC : Total Capacity ( $\times 10^3$  Btu/h)

TPC : Total Power Consumption (kW)


2. Above data is for heating operation without any frost.

How to operate with fixed operational frequency of the compressor.


1. Press the EMERGENCY OPERATION switch on the front of the indoor unit, and select either EMERGENCY COOL mode or EMERGENCY HEAT mode before starting to operate the air conditioner.
2. The compressor starts with operational frequency.
3. The fan speed of the indoor unit is High.
4. This operation continues for 30 minutes.
5. In order to release this operation, press the EMERGENCY OPERATION switch or press any button on the remote controller.

## 7-2. PERFORMANCE CURVE


### Cooling




#### MUZ-HM09NA(H) MUZ-HM09NA2




#### MUZ-HM12NA(H) MUZ-HM12NA2




#### MUZ-HM15NA(H) MUZ-HM15NA2



#### MUZ-HM18NA(H) MUZ-HM18NA2




#### MUZ-HM24NA(H) MUZ-HM24NA2




This value of frequency is not the same as the actual frequency in operating. Refer to 7-5 and 7-6 for the relationships between frequency and capacity.


## Heating




### MUZ-HM09NA(H) MUZ-HM09NA2




### MUZ-HM12NA(H) MUZ-HM12NA2




### MUZ-HM15NA(H) MUZ-HM15NA2



### MUZ-HM18NA(H) MUZ-HM18NA2



### MUZ-HM24NA(H) MUZ-HM24NA2



This value of frequency is not the same as the actual frequency in operating. Refer to 7-5 and 7-6 for the relationships between frequency and capacity.



### 7-3. CONDENSING PRESSURE

#### Cooling



Data are based on the condition of indoor humidity 50 %.

Air flow should be set to High speed.



#### MUZ-HM09NA(H) MUZ-HM09NA2




#### MUZ-HM12NA - U1, U2 MUZ-HM12NA2 - U1 MUZ-HM12NAH




#### MUZ-HM12NA - U8 MUZ-HM12NA2 - U8




## MUZ-HM15NA(H) MUZ-HM15NA2



## MUZ-HM18NA(H) MUZ-HM18NA2



## MUZ-HM24NA(H) MUZ-HM24NA2





## Heating

Data are based on the condition of outdoor humidity 75%.



Air flow should be set to High speed.

Data are for heating operation without any frost.



### MUZ-HM09NA(H) MUZ-HM09NA2 MUZ-HM12NA - U1, U2 MUZ-HM12NA2 - U1 MUZ-HM12NAH





### MUZ-HM12NA - U8 MUZ-HM12NA2 - U8





### MUZ-HM15NA(H) MUZ-HM15NA2



## MUZ-HM18NA(H) MUZ-HM18NA2



## MUZ-HM24NA(H) MUZ-HM24NA2



## 7-4. STANDARD OPERATION DATA

Model			MSZ-HM09NA - [U1], [U2]		MSZ-HM09NA - [U8]		
Item		Unit	Cooling	Heating	Cooling	Heating	
Total	Capacity	Btu/h	9,000	10,900	9,000	10,900	
	SHF	—	0.82	—	0.82	—	
	Input	kW	0.750	0.900	0.750	0.900	
	Rated frequency	Hz	59.5	79.0	59.5	77.5	
Electrical circuit	Indoor unit		MSZ-HM09NA		MSZ-HM09NA		
	Power supply	V, phase, Hz	208/230, 1, 60				
	Input	kW	0.022	0.023	0.022	0.023	
	Fan motor current	A	0.24/0.22	0.25/0.23	0.24/0.22	0.25/0.23	
	Outdoor unit		MUZ-HM09NA - [U1], [U2] MUZ-HM09NA2 - [U1] MUZ-HM09NAH		MUZ-HM09NA - [U8] MUZ-HM09NA2 - [U8]		
	Power supply	V, phase, Hz	208/230, 1, 60				
	Input	kW	0.728	0.877	0.728	0.877	
	Comp. current	A	3.64/3.29	4.25/3.85	3.32/3.00	3.66/3.31	
	Fan motor current	A	0.27/0.24	0.30/0.27	0.27/0.24	0.30/0.27	
	Refrigerant circuit	Condensing pressure	PSIG	384	331	389	331
Suction pressure		PSIG	152	102	151	103	
Discharge temperature		°F	151	155	154	152	
Condensing temperature		°F	113	101	115	103	
Suction temperature		°F	58	41	59	39	
Comp. shell bottom temperature		°F	146	149	151	149	
Ref. pipe length		ft.	25				
Refrigerant charge (R410A)		1 lb. 12 oz.					
Indoor unit	Intake air temperature	DB	°F	80	70	80	70
		WB	°F	67	60	67	60
	Discharge air temperature	DB	°F	60	97	60	97
		WB	°F	58	—	58	—
	Fan speed (High)		rpm	1,020	1,040	1,020	1,040
Airflow (High)		CFM	367 (Wet)	413	367 (Wet)	413	
Outdoor unit	Intake air temperature	DB	°F	95	47	95	47
		WB	°F	—	43	—	43
	Fan speed		rpm	800	850	800	850
	Airflow		CFM	1151	1225	1151	1225






Model			MSZ-HM12NA - <span>U1</span> , <span>U2</span>		MSZ-HM12NA - <span>U8</span>		
Item		Unit	Cooling	Heating	Cooling	Heating	
Total	Capacity	Btu/h	12,000	12,200	12,000	14,400	
	SHF	—	0.77	—	0.77	—	
	Input	kW	1.210	0.990	1.210	0.990	
	Rated frequency	Hz	89.0	90.0	69.0	77.0	
Electrical circuit	Indoor unit		MSZ-HM12NA		MSZ-HM12NA		
	Power supply	V, phase, Hz	208/230, 1, 60				
	Input	kW	0.022	0.023	0.022	0.023	
	Fan motor current	A	0.24/0.22	0.25/0.23	0.24/0.22	0.25/0.23	
	Outdoor unit		MUZ-HM12NA - <span>U1</span> , <span>U2</span> MUZ-HM12NA2 - <span>U1</span> MUZ-HM12NAH		MUZ-HM12NA - <span>U8</span> MUZ-HM12NA2 - <span>U8</span>		
	Power supply	V, phase, Hz	208/230, 1, 60				
	Input	kW	1.188	0.967	1.188	0.967	
	Comp. current	A	5.61/5.08	4.56/4.13	4.39/3.97	5.41/4.89	
	Fan motor current	A	0.27/0.24	0.30/0.27	0.34/0.31	0.31/0.28	
	Refrigerant circuit	Condensing pressure	PSIG	429	347	389	397
Suction pressure		PSIG	135	99	133	104	
Discharge temperature		°F	180	165	163	162	
Condensing temperature		°F	120	104	115	116	
Suction temperature		°F	60	41	56	35	
Comp. shell bottom temperature		°F	174	157	158	158	
Ref. pipe length		ft.	25				
Refrigerant charge (R410A)		1 lb. 12 oz.		2 lb. 9 oz.			
Indoor unit	Intake air temperature	DB	°F	80	70	80	70
		WB	°F	67	60	67	60
	Discharge air temperature	DB	°F	56	108	56	108
		WB	°F	55	—	55	—
	Fan speed (High)	rpm	1,020	1,040	1,020	1,040	
Airflow (High)	CFM	367 (Wet)	413	367 (Wet)	413		
Outdoor unit	Intake air temperature	DB	°F	95	47	95	47
		WB	°F	—	43	—	43
	Fan speed	rpm	800	850	900	860	
	Airflow	CFM	1151	1225	1229	1172	


Model			MSZ-HM15NA		MSZ-HM18NA		MSZ-HM24NA	
Item		Unit	Cooling	Heating	Cooling	Heating	Cooling	Heating
Total	Capacity	Btu/h	14,000	18,000	17,200	18,000	22,500	26,000
	SHF	—	0.78	—	0.86	—	0.89	—
	Input	kW	1.17	1.60	1.64	1.59	2.63	2.5
	Rated frequency	Hz	56.5	74	68	74	98	108
Electrical circuit	Indoor unit		MSZ-HM15NA		MSZ-HM18NA		MSZ-HM24NA	
	Power supply	V, phase, Hz	208/230, 1, 60					
	Input	kW	0.043	0.030	0.042	0.042	0.055	
	Fan motor current	A	0.43/0.39	0.34/0.31	0.44/0.40	0.44/0.40	0.55/0.50	
	Outdoor unit		MUZ-HM15NA(H) MUZ-HM15NA2		MUZ-HM18NA(H) MUZ-HM18NA2		MUZ-HM24NA(H) MUZ-HM24NA2	
	Power supply	V, phase, Hz	208/230, 1, 60					
	Input	kW	1.127	1.570	1.598	1.548	2.575	2.445
	Comp. current	A	4.91/4.44	7.11/6.43	7.22/6.53	7.11/6.43	11.11/10.05	10.56/9.55
	Fan motor current	A	0.41/0.37	0.40/0.36	0.41/0.37	0.40/0.36	1.05/0.95	1.05/0.95
Refrigerant circuit	Condensing pressure	PSIG	396	427	423	361	404	403
	Suction pressure	PSIG	138	98	144	99	127	94
	Discharge temperature	°F	168	178	165	161	174	194
	Condensing temperature	°F	115	120	120	108	116	116
	Suction temperature	°F	61	31	54	35	54	44
	Comp. shell bottom temperature	°F	152	158	149	143	173	192
	Ref. pipe length	ft.	25					
	Refrigerant charge (R410A)		2 lb. 9 oz.		2 lb. 10 oz.		3 lb 9 oz.	
Indoor unit	Intake air temperature	DB °F	80	70	80	70	80	70
		WB °F	67	60	67	60	67	60
	Discharge air temperature	DB °F	58	114	58	114	57	108
		WB °F	56	—	56	—	56	—
	Fan speed (High)	rpm	1,280	1,140	1,140	1,140	1,250	1,250
Airflow (High)	CFM	498 (Wet)	463	562 (Wet)	625	632 (Wet)	702	
Outdoor unit	Intake air temperature	DB °F	95	47	95	47	95	47
		WB °F	—	43	—	43	—	43
	Fan speed	rpm	910	900	910	900	810	810
	Airflow	CFM	1,243	1,229	1,243	1,229	1,691	1,691

## 7-5. CAPACITY AND INPUT CORRECTION BY INVERTER OUTPUT FREQUENCY


### MUZ-HM09NA - U1, U2 MUZ-HM09NA2 - U1 MUZ-HM09NAH




### MUZ-HM09NA - U8 MUZ-HM09NA2 - U8




### MUZ-HM12NA - U1, U2 MUZ-HM12NA2 - U1 MUZ-HM12NAH




### MUZ-HM12NA - U8 MUZ-HM12NA2 - U8




### MUZ-HM15NA(H) MUZ-HM15NA2



### MUZ-HM18NA(H) MUZ-HM18NA2



### MUZ-HM24NA(H) MUZ-HM24NA2



## 7-6. HOW TO OPERATE FIXED-FREQUENCY OPERATION (Test run operation)

1. Press EMERGENCY OPERATION switch to start COOL or HEAT mode (COOL: Press once, HEAT: Press twice).
2. Test run operation starts and continues to operate for 30 minutes.
3. Compressor operates at rated frequency in COOL mode or 58 Hz in HEAT mode.
4. Indoor fan operates at High speed.
5. After 30 minutes, test run operation finishes and EMERGENCY OPERATION starts (operation frequency of compressor varies).
6. To cancel test run operation (EMERGENCY OPERATION), press EMERGENCY OPERATION switch or any button on remote controller.


MUZ-HM09NA MUZ-HM09NA2 MUZ-HM09NAH MUZ-HM12NA MUZ-HM12NA2 MUZ-HM12NAH  
 MUZ-HM15NA MUZ-HM15NA2 MUZ-HM15NAH MUZ-HM18NA MUZ-HM18NA2 MUZ-HM18NAH  
 MUZ-HM24NA MUZ-HM24NA2 MUZ-HM24NAH

### 8-1. OUTDOOR FAN MOTOR CONTROL

The fan motor turns ON/OFF, interlocking with the compressor.

[ON] The fan motor turns ON 5 seconds before the compressor starts up.

[OFF] The fan motor turns OFF 15 seconds after the compressor has stopped running.




### 8-2. R.V. COIL CONTROL

Heating ..... ON

Cooling ..... OFF

Dry ..... OFF

**NOTE:** The 4-way valve reverses for 5 seconds right before start-up of the compressor.



### 8-3. RELATION BETWEEN MAIN SENSOR AND ACTUATOR

Sensor	Purpose	Actuator					
		Compressor	LEV	Outdoor fan motor	R.V. coil	Indoor fan motor	Defrost heater *
Discharge temperature thermistor	Protection	○	○				
Indoor coil temperature thermistor	Cooling: Coil frost prevention	○					
	Heating: High pressure protection	○	○				
Defrost thermistor	Heating: Defrosting	○	○	○	○	○	
Fin temperature thermistor	Protection	○		○			
Ambient temperature thermistor	Cooling: Low ambient temperature operation	○	○	○			
	Heating: Defrosting (Heater)						○
Outdoor heat exchanger temperature thermistor	Cooling: Low ambient temperature operation	○	○	○			
	Cooling: High pressure protection	○	○	○			

\* Optional parts

MUZ-HM09NA MUZ-HM09NA2 MUZ-HM09NAH MUZ-HM12NA MUZ-HM12NA2 MUZ-HM12NAH  
 MUZ-HM15NA MUZ-HM15NA2 MUZ-HM15NAH MUZ-HM18NA MUZ-HM18NA2 MUZ-HM18NAH  
 MUZ-HM24NA MUZ-HM24NA2 MUZ-HM24NAH

### 9-1. CHANGE IN DEFROST SETTING

#### Changing defrost finish temperature

<JS> To change the defrost finish temperature, cut/solder the JS wire of the outdoor inverter P.C. board (Refer to 10-6.1.).

Jumper		Defrost finish temperature				
		MUZ-HM09/12 - <span>U1</span> , <span>U2</span>	MUZ-HM09 - <span>U8</span>	MUZ-HM12 - <span>U8</span>	MUZ-HM15/18	MUZ-HM24
JS	Soldered (Initial setting)	52°F (11°C)	41°F (5°C)	50°F (10°C)	41°F (5°C)	50°F (10°C)
	None (Cut)	52°F (11°C)	46°F (8°C)	55°F (13°C)	50°F (10°C)	64°F (18°C)

### 9-2. PRE-HEAT CONTROL SETTING

When moisture gets into the refrigerant cycle, it may interfere with the start-up of the compressor at low outside temperature. The pre-heat control prevents this interference. The pre-heat control turns ON when the discharge temperature thermistor is 68°F (20°C) or below. When the pre-heat control turns ON, the compressor is energized. (About 50 W)

#### Pre-heat control setting

<JK>

ON: To activate the pre-heat control, cut JK wire of the inverter P.C. board.

OFF: To deactivate the pre-heat control, solder JK wire of the inverter P.C. board.

(Refer to 10-6.1)

Jumper		Pre-heat control setting
JK	Soldered	Deactivated (Factory setting)
	Cut	Activated

**NOTE:** When the inverter P.C. board is replaced, check the jumper wires, and cut/solder them if necessary.

MUZ-HM09NA MUZ-HM09NA2 MUZ-HM09NAH MUZ-HM12NA MUZ-HM12NA2 MUZ-HM12NAH  
 MUZ-HM15NA MUZ-HM15NA2 MUZ-HM15NAH MUZ-HM18NA MUZ-HM18NA2 MUZ-HM18NAH  
 MUZ-HM24NA MUZ-HM24NA2 MUZ-HM24NAH

### 10-1. CAUTIONS ON TROUBLESHOOTING

#### 1. Before troubleshooting, check the following

- 1) Check the power supply voltage.
- 2) Check the indoor/outdoor connecting wire for miswiring.

#### 2. Take care of the following during servicing

- 1) Before servicing the air conditioner, be sure to turn OFF the main unit first with the remote controller, then after confirming the horizontal vane is closed, turn off the breaker and/or disconnect the power plug.
- 2) Be sure to turn OFF the power supply before removing the front panel, the cabinet, the top panel, and the electronic control P.C. board.
- 3) When removing the electrical parts, be careful of the residual voltage of smoothing capacitor.
- 4) When removing the electronic control P.C. board, hold the edge of the board with care NOT to apply stress on the components.

<Incorrect>



Lead wiring

<Correct>



Connector housing

- 5) When connecting or disconnecting the connectors, hold the connector housing. DO NOT pull the lead wires.

#### 3. Troubleshooting procedure

- 1) Check if the OPERATION INDICATOR lamp on the indoor unit is blinking on and off to indicate an abnormality. To make sure, check how many times the OPERATION INDICATOR lamp is blinking on and off before starting service work. (See the service manual of the indoor unit for a description of those failure codes.)
- 2) Before servicing, check that the connector and terminal are connected properly.
- 3) When the electronic control P.C. board seems to be defective, check the copper foil pattern for disconnection and the components for bursting and discoloration.
- 4) Refer to 10-2 and 10-3.

## 10-2. FAILURE MODE RECALL FUNCTION


Outline of the function

This air conditioner can memorize the abnormal condition which has occurred once.

Even though LED indication listed on the troubleshooting check table (10-3.) disappears, the memorized failure details can be recalled.


### 1. Flow chart of failure mode recall function for the indoor/outdoor unit

Operational procedure




**NOTE:** 1. Make sure to release the failure mode recall function after it is set up, otherwise the unit cannot operate properly.  
2. If the abnormal condition is not deleted from the memory, the last abnormal condition is kept memorized.

※2. Blinking pattern when the indoor unit is abnormal:




※3. Blinking pattern when the outdoor unit is abnormal:






## 2. Flow chart of the detailed outdoor unit failure mode recall function

### Operational procedure



**NOTE:** 1. Make sure to release the failure mode recall function after it is set up, otherwise the unit cannot operate properly.  
2. If the abnormal condition is not deleted from the memory, the last abnormal condition is kept memorized.

※2. Blinking pattern when outdoor unit is abnormal:



--

### 3. Table of outdoor unit failure mode recall function

**NOTE:** Blinking patterns of this mode differ from the ones of TROUBLESHOOTING CHECK TABLE (10-3.).

**MUZ-HM09NA MUZ-HM09NA2 MUZ-HM09NAH**

**MUZ-HM12NA MUZ-HM12NA2 MUZ-HM12NAH**

OPERATION INDICATOR upper lamp (Indoor unit)	Abnormal point (Failure mode / protection)	LED indication (Outdoor P.C. board)	Condition	Remedy	Indoor/ outdoor unit failure mode recall function	Outdoor unit failure mode recall function
OFF	None (Normal)	—	—	—	—	—
2-time blink 2.5 seconds OFF	Outdoor power system	—	Overcurrent protection cut-out operates 3 consecutive times within 1 minute after the compressor gets started.	<ul style="list-style-type: none"> <li>•Reconnect connectors.</li> <li>•Refer to 10-5. Ⓐ "How to check inverter/ compressor".</li> <li>•Check the stop valve.</li> </ul>	○	○
3-time blink 2.5 seconds OFF	Discharge temperature thermistor	1-time blink every 2.5 seconds	Thermistor shorts or opens during compressor running.	<ul style="list-style-type: none"> <li>•Refer to 10-5. Ⓒ "Check of outdoor thermistors". Defective outdoor thermistors can be identified by checking the blinking pattern of LED.</li> </ul>	○	○
	Defrost thermistor					
	Fin temperature thermistor	3-time blink 2.5 seconds OFF				
	P.C. board temperature thermistor	4-time blink 2.5 seconds OFF				
	Ambient temperature thermistor	2-time blink 2.5 seconds OFF				
4-time blink 2.5 seconds OFF	Overcurrent	11-time blink 2.5 seconds OFF	Large current flows into intelligent power module/ power module *1.	<ul style="list-style-type: none"> <li>•Reconnect compressor connector.</li> <li>•Refer to 10-5. Ⓐ "How to check inverter/ compressor".</li> <li>•Check the stop valve.</li> </ul>	—	○
	Compressor synchronous abnormality (Compressor start-up failure protection)	12-time blink 2.5 seconds OFF	Waveform of compressor current is distorted.	<ul style="list-style-type: none"> <li>•Reconnect compressor connector.</li> <li>•Refer to 10-5. Ⓐ "How to check inverter/ compressor".</li> </ul>	—	○
5-time blink 2.5 seconds OFF	Discharge temperature	—	Temperature of discharge temperature thermistor exceeds 241°F (116°C), compressor stops. Compressor can restart if discharge temperature thermistor reads 212°F (100°C) or less 3 minutes later.	<ul style="list-style-type: none"> <li>•Check the refrigerant circuit and the refrigerant amount.</li> <li>•Refer to 10-5. Ⓖ "Check of LEV".</li> </ul>	—	○
6-time blink 2.5 seconds OFF	High pressure	—	Temperature of indoor coil thermistor exceeds 158°F (70°C) in HEAT mode. Temperature of outdoor heat exchanger temperature thermistor exceeds 158°F (70°C) in COOL mode.	<ul style="list-style-type: none"> <li>•Check the refrigerant circuit and the refrigerant amount.</li> <li>•Check the stop valve.</li> </ul>	—	○
7-time blink 2.5 seconds OFF	Fin temperature/ P.C. board temperature	7-time blink 2.5 seconds OFF	Temperature of fin temperature thermistor on the inverter P.C. board exceeds 167 - 176°F (75 - 80°C), or temperature of P.C. board temperature thermistor on the inverter P.C. board exceeds 158 - 167°F (70 - 75°C).	<ul style="list-style-type: none"> <li>•Check around the outdoor unit.</li> <li>•Check the outdoor unit air passage.</li> <li>•Refer to 10-5. Ⓓ "Check of outdoor fan motor".</li> </ul>	—	○
8-time blink 2.5 seconds OFF	Outdoor fan motor	—	Outdoor fan has stopped 3 times in a row within 30 seconds after outdoor fan start-up.	<ul style="list-style-type: none"> <li>•Refer to 10-5. Ⓓ "Check of outdoor fan motor". Refer to 10-5. Ⓔ "Check of inverter P.C. board".</li> </ul>	—	○
9-time blink 2.5 seconds OFF	Nonvolatile memory data	5-time blink 2.5 seconds OFF	Nonvolatile memory data cannot be read properly.	<ul style="list-style-type: none"> <li>•Replace the inverter P.C. board.</li> </ul>	○	○
10-time blink 2.5 seconds OFF	Discharge temperature	—	Temperature of discharge temperature thermistor has been 122°F (50°C) or less for 20 minutes.	<ul style="list-style-type: none"> <li>•Refer to 10-5. Ⓖ "Check of LEV".</li> <li>•Check the refrigerant circuit and the refrigerant amount.</li> </ul>	—	○

**NOTE:** Blinking patterns of this mode differ from the ones of TROUBLESHOOTING CHECK TABLE (10-3.).

OPERATION INDICATOR upper lamp (Indoor unit)	Abnormal point (Failure mode / protection)	LED indication (Outdoor P.C. board)	Condition	Remedy	Indoor/ outdoor unit failure mode recall function	Outdoor unit failure mode recall function
11-time blink 2.5 seconds OFF	Bus-bar voltage (DC)	8-time blink 2.5 seconds OFF	Bus-bar voltage of inverter cannot be detected normally.	•Refer to 10-5. ⑥ "How to check inverter/ compressor".	—	○
	Each phase current of compressor	9-time blink 2.5 seconds OFF	Each phase current of compressor cannot be detected normally.			
12-time blink 2.5 seconds OFF	Overcurrent Compressor open-phase	10-time blink 2.5 seconds OFF	Large current flows into intelligent power module (IPM)/power module (IPM) *1. The open-phase operation of compressor is detected. The interphase short circuit occurs in the output of the intelligent power module (IPM)/power module (IPM) *1. The compressor winding shorts circuit.	•Reconnect compressor connector. •Refer to 10-5. ⑥ "How to check inverter/ compressor".	—	○
14-time blink 2.5 seconds OFF	Stop valve (Closed valve)	14-time blink 2.5 seconds OFF	Closed valve is detected by compressor current.	•Check the stop valve	○	○
	4-way valve/ Pipe temperature	16-time blink 2.5 seconds OFF	The 4-way valve does not work properly. The indoor coil thermistor detects an abnormal temperature.	•Check the 4-way valve. •Replace the inverter P.C. board.		
16-time blink 2.5 seconds OFF	Outdoor refrigerant system abnormality (MUZ-HM09/12NA(2) - <span style="border: 1px solid black; padding: 0 2px;">U1</span> MUZ-HM09/12NA - <span style="border: 1px solid black; padding: 0 2px;">U2</span> MUZ-HM09/12NAH)	1-time blink 2.5 seconds OFF	A closed valve and air trapped in the refrigerant circuit are detected based on the temperature sensed by the indoor and outdoor thermistors and the current of the compressor.	•Check for a gas leak in a connecting piping etc. •Check the stop valve. •Refer to 10-5. ⑥ "Check of outdoor refrigerant circuit".	○	○

**MUZ-HM15NA MUZ-HM15NA2 MUZ-HM15NAH**  
**MUZ-HM18NA MUZ-HM18NA2 MUZ-HM18NAH**  
**MUZ-HM24NA MUZ-HM24NA2 MUZ-HM24NAH**

**NOTE:** Blinking patterns of this mode differ from the ones of TROUBLESHOOTING CHECK TABLE (10-3.).


The upper lamp of the OPERATION INDICATOR lamp (Indoor unit)	Abnormal point (Failure mode/protection)	LED indication (Outdoor P.C. board)	Condition	Remedy	Indoor/outdoor unit failure mode recall function	Outdoor unit failure mode recall function
OFF	None (Normal)	—	—	—	—	—
1-time blink 2.5 seconds OFF	Indoor/outdoor communication, receiving error	—	Any signals from the inverter P.C. board cannot be received normally for 3 minutes.	•Refer to 10-5. ㉔ How to check miswiring and serial signal error.	○	○
	Indoor/outdoor communication, receiving error	—	Although the inverter P.C. board sends signal "0", signal "1" has been received 30 consecutive times.	•Refer to 10-5. ㉔ How to check miswiring and serial signal error.		
2-time blink 2.5 seconds OFF	Outdoor power system	—	Overcurrent protection cut-out operates 3 consecutive times within 1 minute after the compressor gets started.	•Reconnect connectors. •Refer to 10-5. ㉔ "How to check inverter/ compressor". •Check stop valve.	○	○
3-time blink 2.5 seconds OFF	Discharge temperature thermistor	1-time blink every 2.5 seconds	Thermistor shorts or opens during compressor running.	•Refer to 10-5.㉔ "Check of outdoor thermistors". Defective outdoor thermistors can be identified by checking the blinking pattern of LED.	○	○
	Defrost thermistor					
	Fin temperature thermistor	3-time blink 2.5 seconds OFF				
	P.C. board temperature thermistor	4-time blink 2.5 seconds OFF				
	Ambient temperature thermistor	2-time blink 2.5 seconds OFF				
	Outdoor heat exchanger temperature thermistor	—				
4-time blink 2.5 seconds OFF	Overcurrent	11-time blink 2.5 seconds OFF	Large current flows into the power module (IPM) (MUZ-HM09/12NA(2) - [U8]/(IC700) (MUZ-HM09/12/15/18/24NA(2) - [U1] MUZ-HM09/12/15/18/24NAH MUZ-HM09/12/15/18NA - [U2]).	•Reconnect compressor connector. •Refer to 10-5.㉔ "How to check inverter/ compressor". •Check stop valve.	—	○
	Compressor synchronous abnormality (Compressor start-up failure protection)	12-time blink 2.5 seconds OFF	Waveform of compressor current is distorted.	•Reconnect compressor connector. •Refer to 10-5.㉔ "How to check inverter/ compressor".	—	○
5-time blink 2.5 seconds OFF	Discharge temperature	—	Temperature of discharge temperature thermistor exceeds 241°F (116°C), compressor stops. Compressor can restart if discharge temperature thermistor reads 212°F (100°C) or less 3 minutes later.	•Check refrigerant circuit and refrigerant amount. •Refer to 10-5.㉔ "Check of LEV".	—	○
6-time blink 2.5 seconds OFF	High pressure	—	Temperature indoor coil thermistor exceeds 158°F (70°C) in HEAT mode. Temperature defrost thermistor exceeds 158°F (70°C) in COOL mode.	•Check refrigerant circuit and refrigerant amount. •Check stop valve.	—	○
7-time blink 2.5 seconds OFF	Fin temperature/ P.C. board temperature	7-time blink 2.5 seconds OFF	Temperature of the fin temperature thermistor on the inverter P.C. board exceeds 167 - 187°F (75 - 86°C), or temperature of P.C. board temperature thermistor on the inverter P.C. board exceeds 162 - 185°F (72 - 85°C).	•Check around outdoor unit. •Check outdoor unit air passage. •Refer to 10-5.㉔ "Check of outdoor fan motor".	—	○
8-time blink 2.5 seconds OFF	Outdoor fan motor	—	Outdoor fan has stopped 3 times in a row within 30 seconds after outdoor fan start-up.	•Refer to 10-5.㉔ "Check of outdoor fan motor". Refer to 10-5.㉔ "Check of inverter P.C. board".	—	○
9-time blink 2.5 seconds OFF	Nonvolatile memory data	5-time blink 2.5 seconds OFF	Nonvolatile memory data cannot be read properly.	•Replace the inverter P.C. board.	○	○
	Power module (IPM) (MUZ-HM09/12NA(2) - [U8]/(IC700) (MUZ-HM09/12/15/18/24NA(2) - [U1] MUZ-HM09/12/15/18/24NAH MUZ-HM09/12/15/18NA - [U2])	6-time blink 2.5 seconds OFF	The interface short circuit occurs in the output of the power module (IPM) (MUZ-HM09/12NA(2) - [U8]/(IC700) (MUZ-HM09/12/15/18/24NA(2) - [U1] MUZ-HM09/12/15/18/24NAH MUZ-HM09/12/15/18NA - [U2]). The compressor winding shorts circuit.	•Refer to 10-5. ㉔ "How to check inverter/ compressor".	—	

**NOTE:** Blinking patterns of this mode differ from the ones of TROUBLESHOOTING CHECK TABLE (10-3.).

The upper lamp of the OPERATION INDICATOR lamp (Indoor unit)	Abnormal point (Failure mode/protection)	LED indication (Outdoor P.C. board)	Condition	Remedy	Indoor/outdoor unit failure mode recall function	Outdoor unit failure mode recall function
10-time blink 2.5 seconds OFF	Discharge temperature	—	Temperature of discharge temperature thermistor has been 122°F (50°C) or less for 20 minutes.	•Refer to 10-5. ⑧ "Check of LEV". •Check refrigerant circuit and refrigerant amount.	—	○
11-time blink 2.5 seconds OFF	Bus-bar voltage (DC)	8-time blink 2.5 seconds OFF	Bus-bar voltage of inverter cannot be detected normally.	•Refer to 10-5. ⑨ "How to check inverter/ compressor".	—	○
	Each phase current of compressor	9-time blink 2.5 seconds OFF	Each phase current of compressor cannot be detected normally.			
14-time blink 2.5 seconds OFF	Stop valve (Closed valve)	14-time blink 2.5 seconds OFF	Closed valve is detected by compressor current.	•Check stop valve.	○	○
	4-way valve/ Pipe temperature	16-time blink 2.5 seconds OFF	The 4-way valve does not work properly. The indoor coil thermistor detects an abnormal temperature.	•Check the 4-way valve. •Replace the inverter P.C. board.		
16-time blink 2.5 seconds OFF	Outdoor refrigerant system abnormality	1-time blink 2.5 seconds OFF	A closed valve and air trapped in the refrigerant circuit are detected based on the temperature sensed by the indoor and outdoor thermistors and the current of the compressor.	•Check for a gas leak in a connecting piping etc. •Check the stop valve. •Refer to 10-5. ⑩ "Check of outdoor refrigerant circuit".	○	○

### 10-3. TROUBLESHOOTING CHECK TABLE


No.	Symptom	LED indication	Abnormal point/ Condition	Condition	Remedy
1	Outdoor unit does not operate.	1-time blink every 2.5 seconds	Outdoor power system	Overcurrent protection cut-out operates 3 consecutive times within 1 minute after the compressor gets started.	•Reconnect connector of compressor. •Refer to 10-5.④ "How to check inverter/compressor". •Check stop valve.
2			Outdoor thermistors	Discharge temperature thermistor, fin temperature thermistor, defrost thermistor, P.C. board temperature thermistor, outdoor heat exchanger temperature thermistor or ambient temperature thermistor shorts or opens during compressor running.	•Refer to 10-5.⑥ "Check of outdoor thermistors".
3			Outdoor control system	Nonvolatile memory data cannot be read properly.  (The upper lamp of the OPERATION INDICATOR lamp on the indoor unit lights up or blinks 7-time.)	•Replace inverter P.C. board.
4		6-time blink 2.5 seconds OFF	Serial signal	The communication fails between the indoor and outdoor unit for 3 minutes.	•Refer to 10-5.⑧ "How to check miswiring and serial signal error".
5		11-time blink 2.5 seconds OFF	Stop valve/ Closed valve	Closed valve is detected by compressor current.	•Check stop valve.
6		16-time blink 2.5 seconds OFF	4-way valve/ Pipe temperature	The 4-way valve does not work properly. The indoor coil thermistor detects an abnormal temperature.	•Refer to 10-5.⑨ "Check of R.V. coil". •Replace the inverter P.C. board.
7		17-time blink 2.5 seconds OFF (MUZ-HM09/12/15/18/24NA(2) - [U1] MUZ-HM09/12/15/18/24NAH MUZ-HM09/12/15/18NA - [U2])	Outdoor refrigerant system abnormality	A closed valve and air trapped in the refrigerant circuit are detected based on the temperature sensed by the indoor and outdoor thermistors and the current of the compressor.	•Check for a gas leak in a connecting piping etc. •Check the stop valve. •Refer to 10-5.⑩ "Check of outdoor refrigerant circuit".
8	'Outdoor unit stops and restarts 3 minutes later' is repeated.	2-time blink 2.5 seconds OFF	Overcurrent protection	Large current flows into the power module (IPM) (MUZ-HM09/12NA(2) - [U8]/(IC700) (MUZ-HM09/12/15/18/24NA(2) - [U1] MUZ-HM09/12/15/18/24NAH MUZ-HM09/12/15/18NA - [U2]). ※ When overcurrent protection occurs within 10 seconds after compressor starts, compressor restarts after 15 seconds (MUZ-HM09/12NA).	•Reconnect connector of compressor. •Refer to 10-5.④ "How to check inverter/compressor". •Check stop valve.
9		3-time blink 2.5 seconds OFF	Discharge temperature overheat protection	Temperature of discharge temperature thermistor exceeds 241°F (116°C), compressor stops. Compressor can restart if discharge temperature thermistor reads 212°F (100°C) or less 3 minutes later.	•Check refrigerant circuit and refrigerant amount. •Refer to 10-5.⑪ "Check of LEV".
10		4-time blink 2.5 seconds OFF	Fin temperature / P.C. board temperature thermistor overheat protection	Temperature of the fin temperature thermistor on the heat sink exceeds 167 - 176°F (75 - 80°C) (MUZ-HM09/12NA(2) MUZ-HM09/12NAH)/167 - 187°F (75 - 86°C) (MUZ-HM15/18/24NA(2) MUZ-HM15/18/24NAH) or temperature of P.C. board temperature thermistor on the inverter P.C. board exceeds 158 - 167°F (70 - 75°C) (MUZ-HM09/12NA(2) MUZ-HM09/12NAH)/162 - 185°F (72 - 85°C) (MUZ-HM15/18/24NA(2) MUZ-HM15/18/24NAH).	•Check around outdoor unit. •Check outdoor unit air passage. •Refer to 10-5.⑫ "Check of outdoor fan motor".
11		5-time blink 2.5 seconds OFF	High pressure protection	Indoor coil thermistor exceeds 158°F (70°C) in HEAT mode. Defrost thermistor exceeds 158°F (70°C) in COOL mode.	•Check refrigerant circuit and refrigerant amount. •Check stop valve.
12		8-time blink 2.5 seconds OFF	Compressor synchronous abnormality	The waveform of compressor current is distorted.	•Reconnect connector of compressor. •Refer to 10-5.④ "How to check inverter/compressor".
13		10-time blink 2.5 seconds OFF	Outdoor fan motor	Outdoor fan has stopped 3 times in a row within 30 seconds after outdoor fan start-up.	•Refer to 10-5.⑬ "Check of outdoor fan motor". •Refer to 10-5.⑭ "Check of inverter P.C. board".
14		12-time blink 2.5 seconds OFF	Each phase current of compressor	Each phase current of compressor cannot be detected normally.	•Refer to 10-5.④ "How to check inverter/compressor".
15		13-time blink 2.5 seconds OFF	Bus-bar voltage (DC)	Bus-bar voltage of inverter cannot be detected normally.	•Refer to 10-5.④ "How to check inverter/compressor".




No.	Symptom	LED indication	Abnormal point/Condition	Condition	Remedy
16	Outdoor unit operates.	1-time blink 2.5 seconds OFF	Frequency drop by current protection	Current from power outlet is nearing Max. fuse size.	The unit is normal, but check the following. •Check if indoor filters are clogged. •Check if refrigerant is short. •Check if indoor/outdoor unit air circulation is short cycled.
17		3-time blink 2.5 seconds OFF	Frequency drop by high pressure protection	Temperature of indoor coil thermistor exceeds 131 °F (55°C) in HEAT mode, compressor frequency lowers.	
			Frequency drop by defrosting in COOL mode	Indoor coil thermistor reads 46°F (8°C) or less in COOL mode, compressor frequency lowers.	
18		4-time blink 2.5 seconds OFF	Frequency drop by discharge temperature protection	Temperature of discharge temperature thermistor exceeds 232°F (111°C), compressor frequency lowers.	
19		5-time blink 2.5 seconds OFF	Outside temperature thermistor protection	When the outside temperature thermistor shorts or opens, protective operation without that thermistor is performed.	•Refer to 10-5. Ⓒ Check of outdoor thermistors.
20		7-time blink 2.5 seconds OFF	Low discharge temperature protection	Temperature of discharge temperature thermistor has been 122°F (50°C) or less for 20 minutes.	•Refer to 10-5. Ⓒ "Check of LEV". •Check refrigerant circuit and refrigerant amount.
21		8-time blink 2.5 seconds OFF	PAM protection PAM: Pulse Amplitude Modulation	The overcurrent flows into IGBT (Insulated Gate Bipolar transistor: TR821) (MUZ-HM09/12NA(2) - [U8])/PFC (Power factor correction: IC820) (MUZ-HM09/12/15/18/24NA(2) - [U1] MUZ-HM09/12/15/18/24NAH MUZ-HM09/12/15/18NA - [U2] MUZ-HM24NAH) or the bus-bar voltage reaches 320 V (MUZ-HM09/12NA(2) - [U8])/394 V (MUZ-HM09/12/15/18/24NA(2) - [U1] MUZ-HM09/12/15/18/24NAH MUZ-HM09/12/15/18NA - [U2]) or more, PAM stops and restarts.	This is not malfunction. PAM protection will be activated in the following cases: 1 Instantaneous power voltage drop. (Short time power failure) 2 When the power supply voltage is high.
			Zero cross detecting circuit (MUZ-HM09/12NA(2) MUZ-HM09/12NAH)	Zero cross signal for PAM control cannot be detected.	
22		9-time blink 2.5 seconds OFF	Inverter check mode	The connector of compressor is disconnected, inverter check mode starts.	•Check if the connector of the compressor is correctly connected. Refer to 10-5. Ⓐ "How to check inverter/compressor".

**NOTE:** 1. The location of LED is illustrated at the right figure. Refer to 10-6.1.  
 2. LED is lighted during normal operation.  
 3. Blinking patterns of this mode differ from the ones of the failure recall mode.


The blinking frequency shows the number of times the LED blinks after every 2.5-second OFF.  
 (Example) When the blinking frequency is "2".




Inverter P.C. board  
 MUZ-HM09/12NA2  
 MUZ-HM09/12NA - [U1] - [U2]  
 MUZ-HM09/12NAH



MUZ-HM15/18/24NA(2)  
 MUZ-HM15/18/24NAH



Inverter P.C. board  
 MUZ-HM09/12NA - [U8]



#### 10-4. TROUBLE CRITERION OF MAIN PARTS


**MUZ-HM09NA MUZ-HM09NA2 MUZ-HM09NAH MUZ-HM12NA MUZ-HM12NA2 MUZ-HM12NAH  
MUZ-HM15NA MUZ-HM15NA2 MUZ-HM15NAH MUZ-HM18NA MUZ-HM18NA2 MUZ-HM18NAH  
MUZ-HM24NA MUZ-HM24NA2 MUZ-HM24NAH**

Part name	Check method and criterion	Figure																														
Defrost thermistor (RT61) Fin temperature thermistor (RT64) Ambient temperature thermistor (RT65) Outdoor heat exchanger temperature thermistor (RT68)	Measure the resistance with a tester. Refer to 10-6. "Test point diagram and voltage", 1. "Inverter P.C. board", for the chart of thermistor.																															
Discharge temperature thermistor (RT62)	Measure the resistance with a tester. Before measurement, hold the thermistor with your hands to warm it up. Refer to 10-6. "Test point diagram and voltage", 1. "Inverter P.C. board", for the chart of thermistor.																															
Compressor	Measure the resistance between terminals using a tester. [Temperature: 14 - 104°F (-10 - 40°C)] <table><tr><td></td><td colspan="5">Normal (Ω)</td></tr><tr><td></td><td>HM09/12NA(2)- U1</td><td>HM09/12NA- U2 HM09/12NAH- U1</td><td>HM09NA - U8</td><td>HM12NA - U8</td><td>HM15/18/24</td></tr><tr><td>U-V</td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>U-W</td><td>1.26 - 1.72</td><td>1.59 - 2.16</td><td>1.36 - 1.93</td><td>1.52 - 2.17</td><td>0.82 - 1.11</td></tr><tr><td>V-W</td><td></td><td></td><td></td><td></td><td></td></tr></table>		Normal (Ω)						HM09/12NA(2)- U1	HM09/12NA- U2 HM09/12NAH- U1	HM09NA - U8	HM12NA - U8	HM15/18/24	U-V						U-W	1.26 - 1.72	1.59 - 2.16	1.36 - 1.93	1.52 - 2.17	0.82 - 1.11	V-W						
	Normal (Ω)																															
	HM09/12NA(2)- U1	HM09/12NA- U2 HM09/12NAH- U1	HM09NA - U8	HM12NA - U8	HM15/18/24																											
U-V																																
U-W	1.26 - 1.72	1.59 - 2.16	1.36 - 1.93	1.52 - 2.17	0.82 - 1.11																											
V-W																																
Outdoor fan motor	Measure the resistance between lead wires using a tester. [Temperature: 14 - 104°F (-10 - 40°C)] <table><tr><td>Color of lead wire</td><td colspan="3">Normal (Ω)</td></tr><tr><td></td><td>HM09/12- U1, U8 HM15/18- U1</td><td>HM09/12/15/18- U2</td><td>HM24</td></tr><tr><td>RED - BLK BLK - WHT WHT - RED</td><td>29 - 40</td><td>28 - 39</td><td>12 - 16</td></tr></table>	Color of lead wire	Normal (Ω)				HM09/12- U1, U8 HM15/18- U1	HM09/12/15/18- U2	HM24	RED - BLK BLK - WHT WHT - RED	29 - 40	28 - 39	12 - 16																			
Color of lead wire	Normal (Ω)																															
	HM09/12- U1, U8 HM15/18- U1	HM09/12/15/18- U2	HM24																													
RED - BLK BLK - WHT WHT - RED	29 - 40	28 - 39	12 - 16																													
R. V. coil (21S4)	Measure the resistance using a tester. [Temperature: 14 - 104°F (-10 - 40°C)] <table><tr><td colspan="4">Normal (kΩ)</td></tr><tr><td>HM09/12- U1, U8</td><td>HM15/18- U1, U2</td><td>HM24</td><td>HM09/12NA- U2</td></tr><tr><td colspan="3">0.97 - 1.38</td><td>1.65 - 2.48</td></tr></table>	Normal (kΩ)				HM09/12- U1, U8	HM15/18- U1, U2	HM24	HM09/12NA- U2	0.97 - 1.38			1.65 - 2.48																			
Normal (kΩ)																																
HM09/12- U1, U8	HM15/18- U1, U2	HM24	HM09/12NA- U2																													
0.97 - 1.38			1.65 - 2.48																													
Expansion valve coil (LEV)	Measure the resistance using a tester. [Temperature: 14 - 104°F (-10 - 40°C)] <table><tr><td>Color of lead wire</td><td>Normal (Ω)</td></tr><tr><td>RED - ORN</td><td rowspan="5">37 - 54</td></tr><tr><td>RED - WHT</td></tr><tr><td>RED - BLU</td></tr><tr><td>RED - YLW</td></tr><tr><td>RED - YLW</td></tr></table>	Color of lead wire	Normal (Ω)	RED - ORN	37 - 54	RED - WHT	RED - BLU	RED - YLW	RED - YLW																							
Color of lead wire	Normal (Ω)																															
RED - ORN	37 - 54																															
RED - WHT																																
RED - BLU																																
RED - YLW																																
RED - YLW																																
Defrost heater	Measure the resistance using a tester. [Temperature: 14 - 104°F (-10 - 40°C)] <table><tr><td colspan="2">Normal (Ω)</td></tr><tr><td>HM09/12/15/18</td><td>HM24</td></tr><tr><td>349 - 428</td><td>376 - 461</td></tr></table>	Normal (Ω)		HM09/12/15/18	HM24	349 - 428	376 - 461																									
Normal (Ω)																																
HM09/12/15/18	HM24																															
349 - 428	376 - 461																															



## 10-5. TROUBLESHOOTING FLOW

### A How to check inverter/compressor



\*Power module

IPM	HM09/12NA(2) - U8
IC700	HM09/12NA(2) - U1
	HM09/12NA - U2
	HM15/18/24NA(2)
	HM09/12/15/18/24NAH

### B Check of open phase

- With the connector between the compressor and the power module\* disconnected, activate the inverter and check if the inverter is normal by measuring **the voltage balance** between the terminals.

Output voltage is 50 - 130 V. (The voltage may differ according to the tester.)

<< Operation method>>

Start cooling or heating operation by pressing EMERGENCY OPERATION switch on the indoor unit. (TEST RUN OPERATION: Refer to 7-6.)

<<Measurement point>>

At 3 points ※ Measure AC voltage between the lead wires at 3 points.

BLK (U)-WHT (V)

BLK (U)-RED (W)


WHT(V)-RED (W)

**NOTE:** 1. Output voltage varies according to power supply voltage.

2. Measure the voltage by analog type tester.

3. During this check, LED of the inverter P.C. board blinks 9 times. (Refer to 10-6.1.)

### C Check of compressor



## D Check of compressor winding

- Disconnect the connector between the compressor and the power module\*, and measure the resistance between the compressor terminals.

<<Measurement point>>

At 3 points

BLK-WHT

BLK-RED

WHT-RED

※ Measure the resistance between the lead wires at 3 points.

<<Judgement>>

Refer to 10-4.

0 [Ω] ..... Abnormal [short]

Infinite [Ω] ..... Abnormal [open]

**NOTE:** Be sure to zero the ohmmeter before measurement.

\*Power module

IPM	HM09/12NA(2) - U8
IC700	HM09/12NA(2) - U1
	HM09/12NA - U2
	HM15/18/24NA(2)
	HM09/12/15/18/24NAH

## E Check of compressor operation time

- Connect the compressor and activate the inverter. Then measure the time until the inverter stops due to overcurrent.


<<Operation method>>

Start heating or cooling operation by pressing EMERGENCY OPERATION switch on the indoor unit. (TEST RUN OPERATION: Refer to 7-6.)

<<Measurement>>

Measure the time from the start of compressor to the stop of compressor due to overcurrent.

<<Judgement>>



## F Check of compressor start failure

Confirm that ①~④ is normal.

•Electrical circuit check

①. Contact of the compressor connector

②. Output voltage of inverter P.C. board and balance of them (See 10-5.⑥)

③. Direct current voltage between DB61(+) and (-) on the inverter P.C. board

④. Voltage between outdoor terminal block S1-S2

Does the compressor run for 10 seconds or more after it starts?

Yes

Check the refrigerant circuit.  
Check the stop valve.

No


After the compressor is heated with a drier, does the compressor start? ※1

No

Replace the compressor.

Yes

Compressor start failure. Activate pre-heat control.  
(Refer to 9-2. "PRE-HEAT CONTROL SETTING")



※1

Heat the compressor with a drier for about 20 minutes. Do not recover refrigerant gas while heating.

## G Check of outdoor thermistors

Disconnect the connector of thermistor in the inverter P.C. board (see below table), and measure the resistance of thermistor.

Is the resistance of thermistor normal?  
(Refer to 10-6.1.)

No

Replace the thermistor except RT64.  
When RT64 is abnormal, replace the inverter P.C. board.

Yes

Reconnect the connector of thermistor.  
Turn ON the power supply and press EMERGENCY OPERATION switch.

Does the unit operate for 10 minutes or more  
without showing thermistor abnormality?

No

Replace the inverter P.C. board.

Yes

OK  
(Cause is poor contact.)

Thermistor	Symbol	Connector, Pin No.	Board
Defrost	RT61	Between CN641 pin1 and pin2	Inverter P.C. board
Discharge temperature	RT62	Between CN641 pin3 and pin4	
Fin temperature	RT64	Between CN642 pin1 and pin2	
Ambient temperature	RT65	Between CN643 pin1 and pin2	
Outdoor heat exchanger temperature	RT68	Between CN644 pin1 and pin3	

## H Check of R.V. coil

※ First of all, measure the resistance of R.V. coil to check if the coil is defective. Refer to 10-4.

※ Check if there is 208/230 V AC at L1 - L2.

※ In case CN721 is disconnected or R.V. coil is open, voltage is generated between the terminal pins of the connector although no signal is being transmitted to R.V. coil.

Check if CN721 is connected.

### Unit operates in COOL mode even if it is set to HEAT mode.

Disconnect connector between the compressor and the power module\*.  
Turn ON the power supply and press EMERGENCY OPERATION switch twice (HEAT mode).

Is there 208/230 V AC between CN721 ① and ② on the inverter P.C. board 3 minutes after the power supply is turned ON?

No

Replace the inverter P.C. board.

Yes

Replace the 4-way valve.

\*Power module

IPM	HM09/12NA(2) - U8
IC700	HM09/12NA(2) - U1
	HM09/12NA - U2
	HM15/18/24NA(2)
	HM09/12/15/18/24NAH

### Unit operates in HEAT mode even if it is set to COOL mode.

Disconnect connector between the compressor and the power module\*.  
Turn ON the power supply and press EMERGENCY OPERATION switch once (COOL mode).

Is there 208/230 V AC between CN721 ① and ② on the inverter P.C. board 3 minutes after the power supply is turned ON?

Yes

Replace the inverter P.C. board.

No

Replace the 4-way valve.

## ① Check of outdoor fan motor

Check the connection between the connector CN931 and CN932. Disconnect the connectors CN931 and CN932 from the inverter P.C. board.

Is the resistance between each terminal of outdoor fan motor normal? (Refer to 10-4.)

No

Replace the outdoor fan motor.

Yes

Disconnect CN932 from the inverter P.C. board, and turn on the power supply.

Rotate the outdoor fan motor manually and measure the voltage of CN931.  
Between 1(+) and 5(-)  
Between 2(+) and 5(-)  
Between 3(+) and 5(-)

(Fixed to either 5 or 0 V DC)

No

Does the voltage between each terminal become 5 and 0 V D C repeatedly?

Yes


No

Does the outdoor fan motor rotate smoothly?

Yes

Replace the inverter P.C. board.


**Check of power supply**



\*1 Power module

IPM	HM09/12NA(2) - U8
IC700	HM09/12NA(2) - U1
	HM09/12NA - U2
	HM15/18/24NA(2)
	HM09/12/15/18/24NAH

\*2 Bus-bar voltage (DC)



## K Check of LEV (Expansion valve)

Turn ON the power supply.



<Preparation of the remote controller>

① While pressing both OPERATION SELECT button and TOO COOL button on the remote controller at the same time, press RESET button.

② First, release RESET button.

Hold down the other 2 buttons for another 3 seconds.

Make sure that the indicators on the LCD screen shown in the right figure are all displayed. Then release the buttons.



Press STOP/OPERATE (OFF/ON) button of the remote controller (the set temperature is displayed) with the remote controller headed towards the indoor unit. ※1

Expansion valve operates in full-opening direction.

Do you hear the expansion valve "click, click....."?

Do you feel the expansion valve vibrate when touching it?

Yes

OK

No

Is LEV coil properly fixed to the expansion valve?

No

Properly fix the LEV coil to the expansion valve.

Yes

Does the resistance of LEV coil have the characteristics? (Refer to 10-4.)

Yes

Measure each voltage between connector pins of CN724 on the inverter P.C. board.

1. Pin③(-) — Pin①(+)

2. Pin④(-) — Pin①(+)

3. Pin⑤(-) — Pin①(+)

4. Pin⑥(-) — Pin①(+)

Is there about 3 - 5 V AC between each?

**NOTE:** Measure the voltage by an analog tester.

Yes

Replace the expansion valve.

No

Replace the LEV coil.

No


Replace the inverter P.C. board.

※1. Regardless of normal or abnormal condition, a short beep is emitted once the signal is received.

**NOTE:** After check of LEV, take the following action.


1. Turn OFF the power supply and turn it ON again.
2. Press RESET button on the remote controller.

## **L Check of inverter P.C. board**




## **(M) How to check miswiring and serial signal error**

**MUZ-HM09/12NA(2)**  
**MUZ-HM09/12NAH**





**MUZ-HM15/18/24NA(2)**  
**MUZ-HM15/18/24NAH**




## N Check of defrost heater

Check the following points before checking electric continuity.

1. Does the resistance of ambient temperature thermistor have the characteristics? Refer to 10-6.1.
2. Is the resistance of defrost heater normal? Refer to 10-4.
3. Does the heater protector remain conducted (not open)?
4. Are both ambient temperature thermistor and circuit of defrost heater securely connected to connectors?


In HEAT mode, for more than 5 minutes, let the ambient temperature thermistor continue to read 32°F (0°C) or below, and let the defrost thermistor continue to read 30°F (-1°C) or below.

**NOTE:** In case both thermistors are more than the above temperature, cool them with cold water etc...




## O Check of outdoor refrigerant circuit

(MUZ-HM09/12/15/18/24NA(2) - U1 MUZ-HM09/12/15/18NA - U2 MUZ-HM09/12/15/18/24NAH)



\* **CAUTION** : Do not start the operation again to prevent hazards.


## P Electromagnetic noise enters into TV sets or radios






## 10-6. TEST POINT DIAGRAM AND VOLTAGE

### 1. Inverter P.C. board

MUZ-HM09NA- U1 MUZ-HM09NA2- U1 MUZ-HM12NA- U1 MUZ-HM12NA2- U1  
MUZ-HM15NA- U1 MUZ-HM15NA2- U1 MUZ-HM18NA- U1 MUZ-HM18NA2- U1




Defrost thermistor (RT61)  
Ambient temperature thermistor (RT65)  
Outdoor heat exchanger temperature thermistor (RT68)






OBH747F

## 1. Inverter P.C. board

MUZ-HM09NA- U8 MUZ-HM12NA- U8 MUZ-HM09NA2- U8 MUZ-HM12NA2- U8




Defrost thermistor(RT61)  
Ambient temperature thermistor(RT65)  
Outdoor heat exchanger temperature thermistor(RT68)






# 1. Inverter P.C. board

MUZ-HM09NA- U2 MUZ-HM09NAH- U1 MUZ-HM12NA- U2 MUZ-HM12NAH- U1  
 MUZ-HM15NA- U2 MUZ-HM15NAH- U1 MUZ-HM18NA- U2 MUZ-HM18NAH- U1



Defrost thermistor(RT61)  
 Ambient temperature thermistor(RT65)  
 Outdoor heat exchanger temperature thermistor(RT68)




OBH747F






# 1. Inverter P.C. board

## MUZ-HM24NA MUZ-HM24NA2 MUZ-HM24NAH



Defrost thermistor(RT61)  
Ambient temperature thermistor(RT65)  
Outdoor heat exchanger thermistor(RT68)



## &lt;Detaching method of the terminal with locking mechanism&gt;

The terminal which has the locking mechanism can be detached as shown below.



There are 2 types of the terminals with locking mechanism.

The terminal without locking mechanism can be detached by pulling it out.

Check the shape of the terminal before detaching.

(1) Slide the sleeve and check if there is a locking lever or not.

(2) The terminal with this connector shown below has the locking mechanism.



### 11-1. MUZ-HM09NA MUZ-HM09NA2 MUZ-HM09NAH MUZ-HM12NA MUZ-HM12NA2 MUZ-HM12NAH MUZ-HM15NA MUZ-HM15NA2 MUZ-HM15NAH MUZ-HM18NA MUZ-HM18NA2 MUZ-HM18NAH

**NOTE:** Turn OFF the power supply before disassembly.


—————>: Indicates the visible parts in the photos/figures.  
 - - - - ->: Indicates the invisible parts in the photos/figures.

OPERATING PROCEDURE	PHOTOS/FIGURES
<p><b>1. Removing the cabinet</b></p> <ol style="list-style-type: none"> <li>(1) Remove the screw fixing the service panel.</li> <li>(2) Pull down the service panel and remove it.</li> <li>(3) Remove the screws fixing the conduit cover.</li> <li>(4) Remove the conduit cover. (Photo 4)</li> <li>(5) Remove the screw fixing the conduit plate. (Photo 5)</li> <li>(6) Remove the conduit plate.</li> <li>(7) Disconnect the power supply wire and indoor/outdoor connecting wire.</li> <li>(8) Remove the screws fixing the top panel.</li> <li>(9) Remove the top panel.</li> <li>(10) Remove the screws fixing the cabinet.</li> <li>(11) Remove the cabinet.</li> <li>(12) Remove the screws fixing the back panel.</li> <li>(13) Remove the back panel.</li> </ol>	<p><b>Photo 1</b></p> <p><b>Photo 2</b></p> <p><b>Photo 3</b></p>



## OPERATING PROCEDURE

**Photo 4**




### 2. Removing the inverter assembly, inverter P.C. board

- (1) Remove the cabinet and panels. (Refer to section 1.)
- (2) Disconnect the lead wire to the reactor and the following connectors:
  - <Inverter P.C. board>
  - CN721 (R.V. coil)
  - CN722 (Defrost heater) **(MUZ-HM09/12/15/18NAH)**
  - CN931, CN932 (Fan motor)
  - CN641 (Defrost thermistor and discharge temperature thermistor)
  - CN643 (Ambient temperature thermistor)
  - CN644 (Outdoor heat exchanger temperature thermistor)
  - CN724 (LEV)
- (3) Remove the compressor connector (CN61).
- (4) Remove the screws fixing the heat sink support and the separator.
- (5) Remove the fixing screws of the terminal block support and the back panel.
- (6) Remove the inverter assembly.
- (7) Remove the screw of the ground wire and screw of the terminal block support.
- (8) Remove the heat sink support from the P.C. board support.
- (9) Remove the screw of the inverter P.C. board and remove the inverter P.C. board from the P.C. board support.

## PHOTOS/FIGURE

**Photo 5**




**Photo 6**

**MUZ-HM09/12/15/18NA-U2**

**MUZ-HM09/12/15/18/24NAH-U1**


Screws of the heat sink support and the separator



Screws of the terminal block support and the back panel

**Photo 7**  
**Other models**

Screws of the heat sink support and the separator



Screws of the terminal block support and the back panel

## OPERATING PROCEDURE


### 3. Removing R.V. coil

- (1) Remove the cabinet and panels. (Refer to section 1.)
- (2) Disconnect the following connectors:  
<Inverter P.C. board>  
CN721 (R.V. coil)
- (3) Remove the R.V. coil.

## PHOTOS/FIGURES


**Photo 8**

MUZ-HM09/12/15/18NA-U2  
MUZ-HM09/12/15/18NAH-U1




**Photo 9**

**Other models**



**Photo 10**




## OPERATING PROCEDURE

### 4. Removing the discharge temperature thermistor, defrost thermistor, outdoor heat exchanger temperature thermistor and ambient temperature thermistor


- (1) Remove the cabinet and panels. (Refer to section 1.)
- (2) Disconnect the lead wire to the reactor and the following connectors:  
<Inverter P.C. board>  
CN641 (Defrost thermistor and discharge temperature thermistor)  
CN643 (Ambient temperature thermistor)  
CN644 (Outdoor heat exchanger temperature thermistor)
- (3) Pull out the discharge temperature thermistor from its holder.
- (4) Pull out the defrost thermistor from its holder.
- (5) Pull out the outdoor heat exchanger temperature thermistor from its holder.
- (6) Pull out the ambient temperature thermistor from its holder.

## PHOTOS/FIGURES


**Photo 11**  
MUZ-HM09/12NA-U2  
MUZ-HM09/12NAH-U1



**Photo 12**  
MUZ-HM15/18NA-U1, U2  
MUZ-HM15/18NA2-U1  
MUZ-HM15/18NAH-U1



**Photo 13**  
Other models



## OPERATING PROCEDURE

### 5. Removing outdoor fan motor


- (1) Remove the cabinet and panels. (Refer to section 1.)
- (2) Disconnect the following connectors:  
<Inverter P.C. board>  
CN931, CN932 (Fan motor)
- (3) Remove the propeller fan nut.
- (4) Remove the propeller fan.
- (5) Remove the screws fixing the fan motor.
- (6) Remove the fan motor.

**NOTE:** The propeller fan nut is a reverse thread.

## PHOTOS/FIGURE

**Photo 14**

Screws of the outdoor fan motor



Propeller fan

Propeller fan nut

### 6. Removing the compressor and 4-way valve

- (1) Remove the cabinet and panels. (Refer to section 1.)
- (2) Remove the inverter assembly. (Refer to section 2.)
- (3) Remove the screws fixing the reactor.
- (4) Remove the reactor.
- (5) Remove the soundproof felt.
- (6) Recover gas from the refrigerant circuit.  
**NOTE:** Recover gas from the pipes until the pressure gauge shows 0 PSIG.
- (7) Detach the brazed part of the suction and the discharge pipe connected with compressor.
- (8) Remove the nuts fixing the compressor.
- (9) Remove the compressor.
- (10) Detach the brazed part of pipes connected with 4-way valve.

**Photo 15**

Screws of the reactor



Discharge pipe  
brazed part

Suction pipe  
brazed part

**Photo 16**







Screw of the  
R.V. coil

Brazed parts of  
4-way valve



## 11-2. MUZ-HM24NA MUZ-HM24NAH MUZ-HM24NA2

**NOTE:** Turn OFF the power supply before disassembly.

OPERATING PROCEDURE	PHOTOS/FIGURES
<p><b>1. Removing the cabinet</b></p> <ol style="list-style-type: none"> <li>(1) Remove the screws of the service panel.</li> <li>(2) Remove the screws of the top panel.</li> <li>(3) Remove the screw of the valve cover.</li> <li>(4) Remove the service panel.</li> <li>(5) Remove the screws fixing the conduit cover.</li> <li>(6) Remove the conduit cover.</li> <li>(7) Remove the screw of fixing the conduit plate.</li> <li>(8) Remove the conduit plate.</li> <li>(9) Remove the top panel.</li> <li>(10) Remove the valve cover.</li> <li>(11) Disconnect the power supply and indoor/outdoor connecting wire.</li> <li>(12) Remove the screws of the cabinet.</li> <li>(13) Remove the cabinet.</li> <li>(14) Remove the screws of the back panel.</li> <li>(15) Remove the back panel.</li> </ol> <p><b>Photo 3</b></p> <p>Screws of the conduit cover</p>  <p><b>Photo 4</b></p> <p>Screw of the conduit plate</p> 	<p><b>Photo 1</b></p> <p>Screws of the top panel</p> <p>Screws of the cabinet</p> <p>Screws of the cabinet</p>  <p><b>Photo 2</b></p> <p>Screw of the back panel</p> <p>Screws of the top panel</p> <p>Screw of the valve cover</p> <p>Screws of the cabinet</p> <p>Screws of the back panel</p> <p>Screws of the service panel</p> <p>Screws of the cabinet</p> 

## OPERATING PROCEDURE


### 2. Removing the inverter assembly, inverter P.C. board

- (1) Remove the cabinet and panels. (Refer to section 1.)
- (2) Disconnect the lead wire to the reactor and the following connectors:
  - <Inverter P.C. board>
  - CN721 (R.V. coil)
  - CN722 (Defrost heater) (**MUZ-HM24NAH**)
  - CN931, CN932 (Fan motor)
  - CN641 (Defrost thermistor and discharge temperature thermistor)
  - CN643 (Ambient temperature thermistor)
  - CN644 (Outdoor heat exchanger temperature thermistor)
  - CN724 (LEV)
- (3) Remove the compressor connector.
- (4) Remove the screw fixing the heat sink support and the separator.
- (5) Remove the fixing screws of the terminal block support and the back panel.
- (6) Remove the inverter assembly.
- (7) Remove the screw of the ground wire, screw of the P.C. board cover and screws of the terminal block support.
- (8) Remove the heat sink support from the P.C. board support.
- (9) Remove the screw of the inverter P.C. board and the inverter P.C. board from the P.C. board support.

### 3. Removing R.V. coil

- (1) Remove the cabinet and panels. (Refer to section 1.)
- (2) Disconnect the following connector:
  - <Inverter P.C. board>
  - CN721 (R.V. coil)
- (3) Remove the R.V. coil.

Photo 7



## PHOTOS/FIGURE

Photo 5

Screw of the heat sink support and the separator

Screws of the terminal block support and the back panel





Photo 6



## OPERATING PROCEDURE

### 4. Removing the discharge temperature thermistor, defrost thermistor, outdoor heat exchanger temperature thermistor and ambient temperature thermistor

- (1) Remove the cabinet and panels. (Refer to section 1.)
- (2) Disconnect the lead wire to the reactor and the following connectors:  
 <Inverter P.C. board>  
 CN641 (Defrost thermistor and discharge temperature thermistor)  
 CN643 (Ambient temperature thermistor)  
 CN644 (Outdoor heat exchanger temperature thermistor)
- (3) Pull out the discharge temperature thermistor from its holder.
- (4) Pull out the defrost thermistor from its holder.
- (5) Pull out the outdoor heat exchanger temperature thermistor from its holder.
- (6) Pull out the ambient temperature thermistor from its holder.

### 5. Removing outdoor fan motor

- (1) Remove the top panel, cabinet and service panel. (Refer to section 1.)
- (2) Disconnect the following connectors:  
 <Inverter P.C. board>  
 CN931 and CN932 (Fan motor)
- (3) Remove the propeller fan nut.
- (4) Remove the propeller fan.
- (5) Remove the screws fixing the fan motor.
- (6) Remove the fan motor.

**NOTE:** The propeller fan nut is a reverse thread.

### 6. Removing the compressor and 4-way valve


- (1) Remove the top panel, cabinet and service panel. (Refer to section 1.)
- (2) Remove the back panel. (Refer to section 1.)
- (3) Remove the inverter assembly. (Refer to section 2.)
- (4) Recover gas from the refrigerant circuit.

**NOTE:** Recover gas from the pipes until the pressure gauge shows 0 PSIG.


- (5) Detach the brazed part of the suction and the discharge pipe connected with compressor.
- (6) Remove the compressor nuts.
- (7) Remove the compressor.
- (8) Detach the brazed part of 4-way valve and pipe. (Photo 7)

## PHOTOS/FIGURES


**Photo 8**



**Photo 9**



**Photo 10**



# **mitsubishi electric corporation**

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

© Copyright 2015 MITSUBISHI ELECTRIC CORPORATION

Issued: Aug. 2019. No. OBH747 REVISED EDITION-F

Issued: Mar. 2019. No. OBH747 REVISED EDITION-E

Issued: Jul. 2017. No. OBH747 REVISED EDITION-D

Issued: Feb. 2017. No. OBH747 REVISED EDITION-C

Issued: Mar. 2016. No. OBH747 REVISED EDITION-B

Issued: Feb. 2016. No. OBH747 REVISED EDITION-A

Published: Dec. 2015. No. OBH747

Made in Japan

Specifications are subject to change without notice.